

56510 CHEVY COLORADO GMC CANYON IZUZU PICKUP

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Locate the vehicle's tail light wiring harness underneath the truck bed near the drivers side frame rail (A). This harness will have a connectors similar with the connector ends of the T-Connector harness.

2. Separate the vehicle's connectors taking care not to break the locking tabs (B). Check to see that the mating surfaces of the connectors are free of dirt and clean if necessary.



3. Insert the T-Connector harness between the vehicle's connectors (C).


WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage to vehicle and/or personal injury.

4. Locate a suitable grounding point near the connector such as the vehicle's frame or cross member (Do not not drill into vehicle floor or bed). Clean dirt and rustproofing from area. Drill a 3/32" pilot hole and secure white wire with ring terminal using screw provided.

5. Route the T-Connector harness to the center of the vehicle. Secure converter and wires to vehicle cross member or other mounting points using cable ties and double-sided tape provided.





Looking for dependable trailer hitches and towing? Rely on CURT for quality and long-lasting products.