



2007-2012 Jeep Wrangler JK Lift. KJ09140 Rear only

Bill of Materials

BOM for 3/4 kit
MO3762 x 2 Rear spacers

Tools need for installation.

1. Floor jacks , jack stands and wheel chocks.
2. Metric tools.



1. Check the **Bill of Material** for all parts, read the instructions and understand them before you begin this project
2. Place the wheel chocks at the front tires and jack up the rear suspension and support the vehicle at the frame. **NEVER WORK UNDER A UNSUPPORTED VEHICLE. Remove the rear tires.**
3. With the jack under the axle jack it up so you can disconnect the rear shocks and the rear sway bar at the frame rail.
4. Lower the axle and remove the coil springs and install the spacer (MO3762) over the stock isolator and reinstall the coil spring.
5. Jack up the axle and reinstall the shocks and sway bar.
6. Put the rear tires on, torque to factory specs, remove jack stands, lower vehicle and put back on the ground.
7. You will need to have your wheel alignment checked.
8. Check all bolts after 500 miles.

WARNING

This vehicle has been modified to enhance its performance. The steering, braking and handling of this vehicle will differ from standard passenger cars and trucks, This vehicle handles differently from an ordinary vehicle in driving conditions which may occur on streets, highways and off road. Avoid unnecessary abrupt maneuvers, sudden stops, sharp turns and other driving conditions that could cause loss of control, possibly leading to a roll over or other accident that could result in serious injury or death to driver and passengers. If larger tires are installed the speedometer will read lower than the vehicles actual speed.

DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES