



2007-2012 Jeep Wrangler JK Lift. KJ09152 Front only

Bill of Materials

BOM for 2" kit

M20313 x 2 Ft spacers

M20066 X 2 Bump Stop extenders

Tools need for installation.

1. Floor jacks , jack stands and wheel chocks.
2. Metric tools.



1. Check the BOM for all parts and lay out the tools.
2. Jack up the front of the vehicle and support the vehicle at the frame with jack stands. Put wheel chocks behind the rear tires.
3. With the jack under the front axle jack up the axle and remove the front wheels . Disconnect the shocks and sway bar end links and lower the axle and remove the springs and bump stops.
4. Install the front bump stop extenders and install the stock bump stops extenders.
5. Install the front spacers over the stock isolators and reinstall the front coils. Jack up the front axle and reinstall shocks and sway bar end links.
6. Put the front tires on and remove jack stands and put back on the ground.
7. You need to have your wheel alignment checked.
8. Check all bolts after 500 miles.

WARNING

This vehicle has been modified to enhance its performance. The steering, braking and handling of this vehicle will differ from standard passenger cars and trucks, This vehicle handles differently from an ordinary vehicle in driving conditions which may occur on streets, highways and off road. Avoid unnecessary abrupt maneuvers, sudden stops, sharp turns and other driving conditions that could cause loss of control, possibly leading to a roll over or other accident that could result in serious injury or death to driver and passengers. If larger tires are installed the speedometer will read lower than the vehicles actual speed.

DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES