


















Wheel Well Toolbox

DZ 94 / DZ 95

Installation Instructions

<div><div>A</div><div>Wheel Well Toolbox</div><div></div><div>X1</div></div>	<div><div>B</div><div>Left Mounting Bracket</div><div></div><div>X1</div></div>	<div><div>C</div><div>Right Mounting Bracket</div><div></div><div>X1</div></div>			
<div><div>D</div><div>Hinged Panel</div><div></div><div>X1</div></div>	<div><div>E</div><div>Angle Support</div><div></div><div>X2</div></div>	<div><div>F</div><div>Dual-Lock Tape</div><div></div><div>X2</div></div>	<div><div>G</div><div>Foam Tape</div><div></div><div>X2</div></div>	<div><div>H</div><div>#8 X 1/2" Phillips Head Screw</div><div></div><div>X5</div></div>	
<div><div>I</div><div>1/4 x 1" Black Sheet Metal Screw</div><div></div><div>X4</div></div>	<div><div>J</div><div>1/4 x 3/4" Black Hex Head Bolt</div><div></div><div>X8</div></div>	<div><div>K</div><div>1/4" Black Flat Washer</div><div></div><div>X14</div></div>	<div><div>L</div><div>1/4" Black Hex Nut</div><div></div><div>X14</div></div>	<div><div>M</div><div>1/4 x 1" Ribneck Carriage Head Bolt</div><div></div><div>X6</div></div>	<div><div>N</div><div>Roll of Foam Tape</div><div></div><div>X1</div></div>



Tools Required: Outils Nécessaires:





Note: Some adjustment may be needed to the latch catch assembly in the body of this wheel well toolbox. You may have to pull out on the body of the toolbox where the latch catch is located to get the latch to work properly when you first receive this wheel well toolbox due to problems that arise during shipping. If you choose to install the hinged panel (D) then proceed with Step 1 of this instruction. If you choose to not install the hinged panel, then proceed to Step 6.

1

Place foam tape (N) onto the top of angle support (E) as shown below. Cut the foam tape (N) so that it is flush with the ends of angle support (E) as shown below.



**2**

Use the angle support (E) as a guide to mark the hole locations on wheel well toolbox (A) as shown below. You can place the angle support (E) up to the outside of wheel well toolbox (A) as shown below and then pre-drill the holes through the angle support (E) and the wheel well toolbox (A).





3

Place the angle supports (E) into the wheel well toolbox (A) and secure them into place using 1/4 x 1" ribneck carriage head bolts (M), 1/4" flat washers (K), and 1/4" hex nuts (L) as shown. Tighten into place using a 7/16" wrench / or socket.


7/16"**4**

Place the hinged panel assembly (D) into the wheel well toolbox (A) so that it sits on top of the angled supports (E). Press the hinged panel (D) firmly down against the angle supports (E) and use the existing holes in the hinged panel assembly to drill 5/32" holes down through the angle supports (E). Secure the hinged panel assembly (D) to the angle supports (E) using #8 x 1/2" phillips head screw (H). Tighten into place using a phillips head screwdriver until snug.

5/32"**Phillips
Screwdriver**


5

Place dual lock tape (F) onto the hinged panel (D) and wheel well toolbox (A). This dual lock tape (F) will keep the hinged panel (D) in the upright position when not in use.




6

Peel backing off of foam tape (G).




7

Place foam gasket (G) onto the bottom of wheel well toolbox (A). Trim foam gasket (G) flush with the ends of wheel well toolbox (A).





8

Place the wheel well toolbox (A) into the truck bed so that the angled part of the wheel well toolbox (A) is snug up against the angle part of the wheel well of the vehicle. The left and right mounting brackets (B / C) should be placed so that the mounting bracket flange with the two holes is up against the inside lip of the bed rail. The mounting bracket flange with the four holes should be placed up against the outer edges of the wheel well toolbox (A) as shown below. Mark the hole locations from mounting brackets (B / C) on the inside lip of the bed rail and on the outside of wheel well toolbox (A). Note: See Steps 13 - 16 for mounting bracket (C) installation on 1994 - Current Dodge Ram Pickup beds.






9

Remove the wheel well toolbox (A) from the vehicle bed and then use the marked hole locations as a guide to drill a 1/4" hole through the inside lip of the bed rail as shown below. **Note: See Step 13 - 16 for mounting bracket (C) installation on 1994 - Current Dodge Ram Pickup beds.**



**10**

Secure mounting brackets (B / C) to the inside of the vehicle bed rail using 1/4 x 3/4" hex head bolts (J), 1/4" flat washers (K), and 1/4" hex nuts (L) as shown below. Tighten into place using a 7/16" wrench / or socket. **Note: See Steps 13 - 16 for mounting bracket (C) installation on 1994 - Current Dodge Ram Pickup beds.**





11

Place the wheel well toolbox (A) back into the vehicle truck bed inside of mounting brackets (B / C) as shown below. Use the existing holes in mounting brackets (B / C) as a guide to drill two 1/4" holes through the outside of the wheel well toolbox (A). Note: See Steps 13 - 16 for mounting bracket (C) installation on 1994 - Current Dodge Ram Pickup beds.



**12**

Secure mounting brackets (B / C) to the outside of the wheel well toolbox (A) using 1/4 x 3/4" sheet metal screws (J), 1/4" flat washers (K), and 1/4" hex nuts (L) as shown below. Tighten into place using a 7/16" wrench / or socket. Note: See Steps 13 - 16 for mounting bracket (C) installation on 1994 - Current Dodge Ram Pickup beds.





13**Mounting bracket (C) installation - (1994 - Current) Dodge Ram Pickup beds:**

Place mounting bracket (C) up to the wheel well toolbox (A) and the inside edge of the vehicle stake pocket sheet metal as shown below. Use the holes in mounting bracket (C) as a guide to drill 1/4" holes through the outside of wheel well box (A).

**14****Mounting bracket (C) installation - (1994 - Current) Dodge Ram Pickup beds:**



Secure mounting bracket (C) to the outside of the wheel well toolbox (A) using 1/4 x 3/4" sheet metal screws (J), 1/4" flat washers (K), and 1/4" hex nuts (L) as shown below. Tighten into place using a 7/16" wrench / or socket.



15

Mounting bracket (C) installation - (1994 - Current) Dodge Ram Pickup beds:

Use the existing holes in mounting bracket (C) as a guide to drill $\frac{3}{16}$ " holes through the stake pocket sheet metal as shown below.



16

Mounting bracket (C) installation - (1994 - Current) Dodge Ram Pickup beds:

Secure mounting bracket (C) to the stake pocket sheet metal using $\frac{1}{4}$ x 1" black sheet metal screws (I) as shown below. Tighten into place using a $\frac{3}{8}$ " wrench / or socket.

