

# Installation Instructions

## PART NUMBERS: 65075, CQT65075

### Applications:

Years	Make	Models
2005-Current*	Nissan	Frontier
2005-2012	Nissan	Pathfinder
2009-2012	Suzuki	Equator


### Installation Time: **35 min**

The time listed above is the average time for professional installers. If you do not feel comfortable performing this installation on your own or are in need of assistance, please contact a professional installer.



**Representative Vehicle Photo**

### Equipment Required:




### DO NOT EXCEED LOWER OF TOWING VEHICLE MANUFACTURER'S RATING OR:

**CARGO CAPACITY** – Do not exceed  
500 LB. (227 Kg) or Truck **Front**  
Gross Axle Weight Rating, (GAWR).

**9,000 lb.**  
**(4086 Kg)**

**MAXIMUM WINCH LINE PULL**






**Hitch Illustration**


**Always wear SAFETY GLASSES when installing hitch**

# Installation Instructions

**PART NUMBERS: 65075, CQT65075**

## Fastener Kit: 65075F

①	Qty.(4)	Bolt M12 X 1.25 X 40mm Cl10.9	
②	Qty. (4)	Lock washer 1/2"	
③	Qty. (4)	Flat washer 7/16"	



**Figure 2**

### Air dam removal or Optional Air dam trim, and Tow Hook removal.

1. Remove 6 hex fasteners that hold the center lower air dam, using a 10mm socket.
2. Air dam may be returned to owner or optional trim, see figure 2.
3. Remove 2 hex bolts per front tow hook and remove front tow hook(s). Return to vehicle owner.
4. If trimming air dam, reinstall trimmed air dam and 6 hex fasteners, using a 10mm socket.

### Install Hitch

1. Raise hitch into position.
2. Install with supplied M12 bolts, 1/2" lock washers and, 7/16" flat washers as shown in figure 1.
3. **Tighten all M12 fasteners with torque wrench to 76Lb.-Ft. (103 N\*M)**



**Proper torque is needed to keep the hitch secure to the vehicle when towing.**

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.