



Installation Instructions

PART NUMBERS: 76154, 84154, CQT76154


Applications:

Years	Make	Models
2017-Current*	Nissan	Titan

Installation Time: 30 min.

The time listed above is the average time for professional installers. If you do not feel comfortable performing this installation on your own or are in need of assistance, please contact a professional installer.

Equipment Required:




DO NOT EXCEED LOWER OF TOWING VEHICLE MANUFACTURER'S RATING OR:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	8000 Lb. (3632 Kg)	800 Lb. (363 Kg)
Weight Distributing	12,000 Lb. (5448 Kg)	1200 Lb. (545 Kg)



Representative Vehicle Photo






Hitch Illustration

Installation Instructions

PART NUMBERS: 76154, 84154, CQT76154

Fastener Kit: 76154F

①	Qty. (10)	Bolt M12 X 1.25 X 40 CL10.9 Part no. 04263040	
②	Qty. (6)	Conical washer ½ Part no. 01292008	
③	Qty. (4)	Flat Washer ½ (Hardened) Part no. 3306QAD	



**Always wear SAFETY GLASSES
when installing hitch**





Figure 1



Conical Washer
Teeth side
Against hitch

**Factory tow
hook bracket**
Both sides




Figure 2

- 1. Remove tow hook brackets** – Using a 17mm socket, remove factory tow hook brackets (if present) by removing (10) M12 flange head bolts. Return bolts & brackets to vehicle owner. **See Figure 2.** **NOTE:** For vehicles without factory tow hook brackets, it may be necessary to clean the existing weldnuts in frame using a wire brush or compressed air.
- 2. Install hitch** – Raise the hitch into position, raising the passenger's side hitch bracket above the exhaust first, then raise the driver's side into position. Using the supplied hardware, install the M12 bolts, conical toothed washers, and hardened flat washers as shown. **See Figure 1.**
- 3. Tighten all M12 CL10.9 fasteners with torque wrench to 76 Lb.-Ft. (103 N*m)**




Proper torque is needed to keep the hitch secure to the vehicle when towing.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.

1. **Remove tow hook brackets** – Using a 17mm socket, remove factory tow hook brackets (if present) by removing (10) M12 flange head bolts. Return bolts & brackets to vehicle owner. **See Figure 2.** **NOTE:** For vehicles without factory tow hook brackets, it may be necessary to clean the existing weldnuts in frame using a wire brush or compressed air.




2. **Install hitch** – Raise the hitch into position, raising the passenger's side hitch bracket above the exhaust first, then raise the driver's side into position. Using the supplied hardware, install the M12 bolts, conical toothed washers, and hardened flat washers as shown. **See Figure 1.**



3. Tighten all M12 CL10.9 fasteners with torque wrench to 76 Lb.-Ft. (103 N*m)

⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.



Check out a selection of trailer hitches and towing offered in our online store.