

Installation Instructions

PART NUMBERS: 76543, 84543, CQT76543

WARNING

To prevent **SERIOUS INJURY, DEATH or PROPERTY DAMAGE:**

- **ALWAYS** read, understand and follow warnings and instructions for your hitch **BEFORE** installation. Keep for future reference.
- **DO NOT** cut, weld or modify this receiver.
- **CHECK** all fasteners are tight and your hitch is securely mounted to your vehicle periodically.
- **ALWAYS** read, understand and follow all warnings and instructions for your vehicle and for other accessories you will use with your hitch **BEFORE** use.
- **LOAD** the trailer heavier in front.
- **DO NOT** exceed lower of towing vehicle manufacturer's rating or:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	3500 lb. (1588 kg)	525 lb. (238 kg)
Weight Distributing	N/A	N/A

- **ALWAYS** wear your seatbelt.
- **SLOW DOWN** when towing, **NEVER** exceed any posted speed limit.
- If **EXCESS SWAY** occurs, take your foot off the gas pedal and hold the steering wheel as steady as possible. **DO NOT** apply your brakes and **DO NOT** speed up.

Installation Instructions

PART NUMBERS: 76543, 84543, CQT76543


Applications:

Years	Make	Models
2022-Current*	Mitsubishi	Outlander

*Visit our website for the most up to date information regarding application years and trim levels.

Installation Time: **40 min**

The time listed above is the average time for professional installers. If you do not feel comfortable performing this installation on your own or are in need of assistance, please contact a professional installer.




Representative Vehicle Photo

Equipment Required:

Safety Glasses	Ratchet	19mm Sockets	Soapy Water	Exhaust Removal Pliers	Tape
Socket Extension	Die Grinder	Torque Wrench	Wire Brush	Marker	

DO NOT EXCEED LOWER OF TOWING VEHICLE MANUFACTURER'S RATING OR:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	3500 lb. (1588 kg)	525 lb. (238 kg)
Weight Distributing	N/A	N/A





Hitch Illustration

Always wear SAFETY GLASSES when installing hitch

Installation Instructions

PART NUMBERS: 76543, 84543, CQT76543

Fastener Kit: 76543F

①	Qty. (6)	Bolt M12 x 1.25 x 45 CL 8.8	
②	Qty. (6)	Conical Washer 1/2"	





Figure 2






Figure 3



- 1. Lower exhaust muffler:** Use soapy water to lubricate exhaust rubber hangers. Using exhaust removal pliers, remove rubber hangers at (3) rearmost locations. **Note:** Be sure to support exhaust before removing rubber hangers.
- 2. Trim panels:** Using tape and marker, sketch a 2" x 2" square on inside corner of panel under vehicle, both sides. Using die grinder, remove 2" x 2" corner, both sides, see **Figure 2** and **Figure 3**.
- 3. Install hitch:** Use wire brush to clean paint and debris from weldnuts. Raise the hitch into position and secure hitch to vehicle with (3) M12 bolts ① and (3) 1/2" conical washers ②, both sides, see **Figure 1**. **Note:** If necessary, firmly press heat shield up to keep from contacting top of hitch.
- 4. Tighten all M12 fasteners with torque wrench to 76 Ft.-Lb. (103 N*M).**

Proper torque is needed to keep the hitch secure to the vehicle when towing.



- 5. Reinstall the rubber hangers and exhaust muffler.**

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.

1. **Lower exhaust muffler:** Use soapy water to lubricate exhaust rubber hangers. Using exhaust removal pliers, remove rubber hangers at (3) rearmost locations. **Note:** Be sure to support exhaust before removing rubber hangers.




2. **Trim panels:** Using tape and marker, sketch a 2" x 2" square on inside corner of panel under vehicle, both sides. Using die grinder, remove 2" x 2" corner, both sides.



3. **Install hitch:** Use wire brush to clean paint and debris from weldnuts. Raise the hitch into position and secure hitch to vehicle with (3) M12 bolts ① and (3) 1/2" conical washers ②, both sides, see **Figure 1**. **Note:** If necessary, firmly press heat shield up to keep from contacting top of hitch.

Push heat shield up here



4. **Tighten all M12 fasteners with torque wrench to 76 Ft.-Lb. (103 N*M).**

⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.

5. Reinstall the rubber hangers and exhaust muffler.

