

# Installation Instructions


Part Numbers:

**Kia Sedona**

**75894**

**87658**

**44709**



**Do Not Exceed Lower of Towing Vehicle  
Manufacturer's Rating or**

Hitch type	Max Gross Trailer WT (LB)	Max Tongue WT (LB)
Weight Distributing	<b>4000 (1816 Kg)</b>	<b>400 (182 Kg)</b>
Weight Carrying Ball Mount	<b>4000 (1816 Kg)</b>	<b>400 (182 Kg)</b>

## Hitch Shown In Proper Position

**Equipment Required:** Small Philips tip screwdriver, lubricant or soapy water, & spiral wire brush


**Fastener Kit:** 75894F

**Wrenches:** 19mm

**Drill Bits:** None

**Wiring Access Location:** TBD

Accessory Rating	<b>C</b>
------------------	----------



Fasteners typical both sides

①	Qty. (6)	Hex bolt M12X1.25X35 CL8.8	②	Qty. (6)	Conical washer 1/2
---	----------	----------------------------	---	----------	--------------------

Note: If necessary clean the threads to the existing weldnuts. Carefully run the M12 bolts into the weld nuts or use spiral wire brush to clean the threads.

1. Remove appearance panel from the drivers side, if present. Remove the plastic rivets that fasten the appearance panel to the vehicle. Using a small Philips tip screwdriver, unscrew plastic screws when loose pull the remaining plastic rivet out. Return to owner.
2. Lower exhaust by removing rubber isolators from muffler hangers. Spraying a lubricant or soapy water on the metal hanger rod and the rubber isolator helps removal.
3. Raise hitch on the passenger side over exhaust pipe and slowly rotate hitch into position.
4. Secure hitch by loosely installing all the bolts.
5. Center hitch on the vehicle, assuring clearance with the exhaust.
6. Tighten all fasteners to the required torque specification.
7. Reattach previously removed exhaust hangers.

Tighten all M12 CL8.8 fasteners with torque wrench to 76 Lb.-Ft. (103 N\*M)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.