


Installation Instructions

Ford – F-Series Pickup Truck

Ford Supercrew Pickup Truck

Part Numbers:
41920



**Do Not Exceed Lower of Towing Vehicle
Manufacturer's Rating or**

Hitch type	Max Gross Trailer WT (LB)	Max Tongue WT (LB)
Weight Distributing	13,000 (5902 kg)	1,300 (590 kg)
Weight Carrying Ball Mount	10,000 (4540 kg)	1,000 (454 kg)

Hitch Shown In Proper Position



Equipment Required:

Fastener Kit: F41920

Wrenches: 3/4", 13/16", 7/8"

Drill Bits: 1/2"

Wiring Access Location: PU1, PU2



①	Qty. (2)	HEX BOLT – 1/2"-13 X 1 3/4" LONG	⑥	Qty. (8)	HEX BOLT – 9/16" -18 X 2"
②	Qty. (4)	HARDEN FLAT WASHER – 1/2"	⑦	Qty. (8)	HARDEN FLAT WASHER – 9/16"
③	Qty. (2)	REINFORCEMENT BRACKET	⑧	Qty. (2)	BLOCK – 1/4 X 1-1/2 X 4.00
④	Qty. (2)	LOCK WASHER – 1/2"	⑨	Qty. (8)	FLANGED LOCKNUT – 9/16"-18
⑤	Qty. (2)	HEX NUT – 1/2"-13	⑩		

NOTE: DUE TO VEHICLE AND TIRE SIZE VARIATION SPARE TIRE MAY HAVE TO BE LOOSENED TO INSTALL HITCH.

1. SCRAPE WAX COATING OFF OF FRAME RAILS AROUND THE EIGHT ATTACHMENTS.
2. INSERT 9/16" HEX BOLTS, HARDENED FLAT WASHERS, AND REINFORCEMENT BRACKETS IN REARMOST ATTACHMENT HOLES IN EACH FRAME RAIL.
3. RAISE HITCH INTO POSITION AND LOOSELY INSTALL FASTENERS AT THE REAR ATTACHMENTS.
4. INSTALL 9/16" HEX BOLTS, HARDENED FLAT WASHERS, AND BLOCKS THRU FORWARD ATTACHMENTS HOLES AND FASTEN WITH LOCKNUTS.
5. USE REINFORCEMENT BRACKET AS A TEMPLATE TO DRILL A 1/2" HOLE THRU THE BUMPER BRACKET INTO THE EXISTING SLOT IN THE FRAME RAIL EACH SIDE.
6. INSERT 1/2" HEX BOLTS, HARDENED FLAT WASHERS THRU REINFORCEMENT BRACKETS AND FASTEN WITH HARDENED FLAT WASHERS, LOCK WASHERS AND NUTS.

Tighten all 1/2" fasteners with torque wrench to 75 Lb.-Ft. (102 n*m)

Tighten all 9/16" fasteners with torque wrench to 110 Lb.-Ft. (149 n*m)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.