



Installation Instructions

Nissan Sentra


(WILL NOT FIT SR MODEL)

Part Numbers:

24907

60338

77294



Drawbar Kit:
3593

**Do Not Exceed Lower of Towing Vehicle
Manufacturer's Rating or**

Hitch type	Max Gross Trailer WT (LB)	Max Tongue WT (LB)
Weight Carrying Ball Mount	2000 (907 Kg)	200 (91 Kg)

Wiring Access Location: PC3,4

Accessory Rating	B
------------------	----------


Hitch Shown In Proper Position

Equipment Required: Power Drill

Fastener Kit: 24907F

Wrenches: 9/16, 11/16


Drill Bits: 1", 7/16



EXAMPLE OF FISHWIRE PROCEDURE

Figure 4

Fishwiring Location



①	Qty. (3)	CARRIAGE BOLT – 7/16-14 X 1.75 GR5	⑥	Qty. (1)	BLOCK .250 x 1.00 x 3.00
②	Qty. (3)	CONICAL WASHER – 7/16"	⑦	Qty. (2)	LOCKNUT FLG 3/8-16
③	Qty. (3)	HEX NUT – 7/16-14	⑧	Qty. (2)	CONICAL WASHER 3/8
④	Qty. (2)	7/16" SQ HOLE WASHER	⑨	Qty. (2)	PULL WIRE – 7/16"
⑤	Qty. (2)	BOLT 3/8-16 X 1.25			

- Hold hitch in place and use as a template to mark holes needed to be drilled in the driver side frame rail. (Hitch can be held up by the tow hook mount and the 3/8" bolts if needed). Remove hitch after holes are marked in their correct locations.
- Fish wire bolts and square hole washers up thru the middle access hole in the frame and out the 2 attachment holes.
- Raise hitch into position over the bolts in the frame and attach the 7/16" conical and nut. 3/8" bolts will push through the passenger side end panel holes that line up with the hitch at the frame rail. Install the 3/8" conical and nuts using a 9/16" socket and a box end wrench on the end panel side.
- Install the 7/16" Carriage Bolt and Block thru the vehicle tow hook and the bracket on hitch. Secure bolt using the 11/16" socket or box end wrench.

Tighten all 7/16" fasteners with torque wrench to 50 Lb.-Ft.

Tighten all 3/8" fasteners with torque wrench to 35 Lb.-Ft.