

Installation Instructions

Mazda 3 sedan

Part Numbers:

24912
60344
77299

**Do Not Exceed Lower of Towing Vehicle
Manufacturer's Rating or**


2000 LB (908 Kg) Max Gross Trailer Weight

200 LB (90.8 Kg) Max Tongue Weight

Accessory Rating

A

Wiring Access Location: PC3, 4



Drawbar Kit:
3593

Drawbar must be used in the **RISE** position only.



Hitch Shown In Proper Position

Equipment Required:


Fastener Kit: 24912F

Wrenches: 11/16

Drill Bits: None



Reverse pull wire procedure



**Note: Fasteners typical
both sides**

①	Qty. (4)	Carriage bolt 7/16-14 X 1.50 GR5	④	Qty. (4)	Hex nut 7/16-14
②	Qty. (4)	Spacer 1/4" X 7/8" X 3"	⑤	Qty. (4)	Pull wire 7/16"
③	Qty. (4)	Conical tooth washer 7/16"			

Note: if additional clearance is needed for installation. Lower exhaust system at the rubber isolators. Spraying a lubricant on the metal hanger rod and the rubber isolator helps removal.

1. Raise the hitch into position, feed the pull wires through the adjacent slots on the hitch.
2. Feed the pull wire into the rearward slot and out the access hole. Attach spacer and carriage bolt to pull wire and feed into frame rail, pull into position. Both sides. See Figure 2. Leave pull wire attached.
3. Using the reverse pull wire procedure Figure 3. Feed the pull wire into position both rails. Leave pull wires attached.
4. Carefully remove pull wires. One at a time place the washer over the pull wire and use it to hold the bolt in place while carefully removing the pull wire, then attach the hex nut.
5. Tighten all fasteners to the required torque specification.

Cequent



Tighten all 7/16-14 Gr5 fasteners with torque wrench to 50 Lb.-Ft. (68 N*M)