



# Installation Instructions

**PART NUMBERS: 75225, 87691, 44778**

## Applications:

Years	Make	Models
2014-Current*	Honda	Pilot
	Acura	MDX

\*Visit our website for the most up to date information regarding application years and trim levels.







## Installation Time: **20 min.**

The time listed above is the average time for professional installers. If you do not feel comfortable performing this installation on your own or are in need of assistance, please contact a professional installer.




**Representative Vehicle Photo**

## Equipment Required:

 Safety Glasses	 Ratchet	 22 mm Sockets	 Torque Wrench	 3" Socket Extension
 Flat Head Screw Driver				

## DO NOT EXCEED LOWER OF TOWING VEHICLE MANUFACTURER'S RATING OR:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	6000 lb. (2724 kg)	900 lb. (409 kg)
Weight Distributing	8000 lb. (3632 kg)	900 lb. (409 kg)





**Hitch Illustration**


**Always wear SAFETY GLASSES when installing hitch**

# Installation Instructions


**PART NUMBERS: 75225, 87691, 44778**

①	Qty. (6)	Bolt M14 1.50 x 45, CL10.9	
②	Qty. (6)	Conical washer 5/8"	

**Fastener Kit: 75225F**



**Figure 2**



**Figure 3**

**NOTE:**  
Hitch does not fit with full size spare tire

1. Spare tire lower down – open the trunk and use the tools under storage compartment to lower down the spare tire, see Figure 2.
2. Hitch installation – raise the hitch into position and loosely install M14 bolt ① and conical washer ② into weldnut, see Figure 3.
3. **Tighten all M14 CL10.9 fasteners with torque wrench to 148 Lb.-Ft. (201 N\*M)**  
**⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.**
4. Raise the spare tire back into position. Make sure the spare tire won't interfere with hitch.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.

1. Lower spare tire – open the trunk and use the tools under storage compartment to lower the spare tire, see Figure 2.




2. Hitch installation – raise the hitch into position and loosely install M14 bolt ① and conical washer ② into weldnut, see Figure 3.



3. **Tighten all M14 CL10.9 fasteners with torque wrench to 148 Lb.-Ft. (201 N\*M)**

**⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.**



4. Raise the spare tire back into position. Make sure the spare tire won't interfere with hitch.

