

# Installation Instructions

## Toyota Venza


Part Numbers:

75663

87521

44604

78235 (U-Haul)



### Hitch Shown In Proper Position

#### Equipment Required:

Fastener Kit: 75663F

Wrenches: 17mm

Do Not Exceed Lower of Towing Vehicle Manufacturer's Rating or

Hitch type	Max Gross Trailer WT (LB)	Max Tongue WT (LB)
Weight Distributing	4000 (1816 Kg)	400 (182 Kg)
Weight Carrying Ball Mount	3500 (1589 Kg)	350 (159 Kg)


Wiring Access Location: SUV3, SUV4

### Note:


#### AWD MODELS

Existing vehicle sway-bar brackets must be removed both sides. Then **must be reinstalled** with hitch & spacer blocks, (Item 3), supplied.

**Figure B.**



**Figure A.**



1	Qty. (6)	M10-1.25 x 40mm CL 10.9 Hex Bolt	3	Qty. (2)	5/16" x 1" x 1-1/2" Block-Spacer, ( AWD vehicles only)
2	Qty. (6)	3/8" Conical toothed Washer			

1. If vehicle is **AWD-(All-Wheel Drive)**, then see **Note & Figure B.** above. It is important to the proper operation of the vehicle to reinstall sway bar brackets properly as shown.
2. If vehicle is **AWD** then remove sway bar brackets both sides, saving existing nuts.
3. Lower exhaust by removing (4) exhaust rubber isolators that support muffler and tailpipe from hangers.
4. Raise hitch into position as shown in **Figure A.** above and install (3) 10mm bolts and toothed washers per side into vehicle frame weldnuts. If vehicle is **AWD** then reinstall sway bar bracket with spacer block supplied between lower vehicle attachment and sway bracket as shown in **Figure B.** both sides, using existing nut for lower attachment.
5. Tighten bolts to proper torque as described below. Raise exhaust and re-attach rubber isolators.

**Cequent**

Tighten all M10-1.25 X 40mm fasteners with torque wrench to 42Lb.-Ft. (57 N\*M)

