

Tote Slide Bracket

Fits DU-HA Tote Part Number: 70103

Tools Needed:

- | | | |
|------------------------------|---------------------|------------------------|
| // 7/16" Wrench or Socket | // Hammer | // Nail or Sharp Punch |
| // 9/16" Wrench | // Drill | // Straight Edge |
| // Phillips Screwdriver – #3 | // 23/64" Drill Bit | // Marker or Pencil |





Installation Instructions:

Decide which direction you'd like the lid to open when determining the location of the Tote in the vehicle. On a pickup truck, we recommend the lid open towards the middle of the truck.


- 1 On the end of the Tote that will face the rear of the vehicle, attach one (K) Stopper to the Tote in each corner with one (L) Bolt – 1/4" x 3/4" and attach (O) Lock Swivel in desired corner.
- 2 Attach (A) Base Plate to each (B) Channel with two (C) Screws – Flat Head 1/4" x 7/16" using a Phillips screwdriver – #3. Attach (M) Lock Latch to the (B) Channel with two (N) Screws – #8 x 5/16". Make sure the location corresponds with the (O) Lock Swivel on the Tote.
- 3 Slide the Tote into (A) Base Plate until the (K) Stoppers contact the (B) Channels.
Note: Make sure the (M) Lock Latch and (O) Lock Swivel are aligned and function properly. Place the Tote and (A) Base Plate with (B) Channels into the vehicle in desired location. Make sure the Tote is positioned properly and the rear door of the vehicle closes without contacting the Tote. It is recommended to have at least 1" clearance in between the Tote and the rear door. Make marks at the location of the (A) Base Plate. Hold bracket firmly in place and remove Tote.

Note: Steps 4, 5, and 6 are for SUV's only. If you do not have an SUV, proceed to Step 7.

- 4 If you have a SUV that has a rear floor compartment, the bracket can be attached to the removable floor panel. Drill holes in the panel with a 5/16" drill bit (in the proper location determined in Step 3) and attach the bracket with the the two (G) Bolt – Hex Head 1/4" x 2", two (H) Washers – Flat 1/4", and two (Q) Nut – 1/4", as pictured. *If you do not have this compartment proceed to Step 5.*
- 5 Re-align the (A) Base Plate to the marks made in Step 3. Using a hammer, tap a nail (or a sharp punch) through the carpet and insulation layers until the vehicle floor (metal) is contacted. Make a small indentation in the floor at the outside of each slot of the Base Plate (A). *Continued...*



Part	Description	Qty
A	Base Plate	1
B	Channel	2
C	Screws – Flat Head 1/4" x 7/16"	4
D	Tool Nut	1
E	Bolt – Hex Head 1/4" x 1-1/2"	1
F	Rivet Nut – 1/4"	3
G	Bolt – Hex Head 1/4" x 2"	2
H	Washers – Flat 1/4"	4
I	Spacers – 1/2"	4
J	Washer – Fender 1.25"	2
K	Stoppers	2
L	Bolt – 1/4" x 3/4"	2
M	Lock Latch	1
N	Screws – #8 x 5/16"	2
O	Lock Swivel	1
P	Adjustable Feet	4
Q	Nut – 1/4"	2
R	Spacers – 1/4"	2



Continued...

- 6 Remove rear trim and roll back carpet and insulation to expose the marks made in Step 5.
- 7 Using a straight edge, draw a line from the left to right marks. Locate one high point in between each set of marks, one on the right and one on the left. Drill one 23/64" hole on each high point on the line. Mark the hole placements onto the insulation and carpet layers and create a hole for the bolt to pass through. If using a drill and standard drill bit:
 - (a) Drill the carpet from the under side.
 - (b) Drill through the insulation with the drill in reverse to reduce binding.*Note: Always protect the opposite side of what you are drilling through.*
- 8
 - (a) Place one (F) Rivet Nut – 1/4" in each hole.
 - (b) Slide (D) Tool Nut, onto (E) Bolt – Hex Head 1/4" x 1-1/2", then thread Bolt into (F) Rivet Nut.
 - (c) Using a 9/16" wrench, hold (D) Tool Nut, and using a 7/16" wrench or socket, tighten (E) Bolt – Hex Head until (F) Rivet Nut is securely installed.*Note: Solid Flange should develop on bottom of Rivet Nut when securely fastened.*
 - (d) Remove (E) Bolt – Hex Head and (D) Tool Nut.
- 9 **SUV's:** (1) Replace the carpet/insulation and snap the plastic trim pieces back into place. (2) Insert two (P) Adjustable Feet into the pre-drilled holes in each (B) Channel, then set the Tote Slide Bracket into place in the SUV. (3) Adjust the (P) Adjustable Feet so the (B) Channels are level with the plastic trim piece. (The Tote needs to clear the trim piece to slide properly.) (4) Place one (J) Washer – Fender 1.25", then a combination of one, two, or three (I) and (R) Spacers over each of the drilled holes in the carpet. (Stack spacers on top of one another to match the height of the Adjustable Feet.) *(Note: The number of spacers used may vary. You may not need to use all of the Spacers.)* (5) Insert two (G) Bolt – Hex Head 1/4" x 2" with two (H) Washers – Flat 1/4" through the slots in the (A) Base Plate, (I) and (R) Spacers, (J) Fender Washer, carpet, and insulation and thread them into the (F) Rivet Nut. Adjust the Tote Slide Bracket left or right to move into desired position. (6) Tighten bolts securely, but do not overtighten.

Pickup Trucks/Other Vehicles: (1) Insert two (P) Adjustable Feet into the pre-drilled holes in each (B) Channel, then set the Tote Slide Bracket into place in the vehicle. Adjust the Adjustable Feet to level as needed. *(Note: You may not need to use the Adjustable Feet unless it's necessary to raise or adjust the height of the Tote Slide Bracket.)* (2) Place one (J) Washer – Fender 1.25", over each (F) Rivet Nut. If there is space between the Tote Slide Bracket and the (J) Washer, then add one, two, or three (I) and (R) Spacers (Stack spacers on top of one another to match the height of the Adjustable Feet.) *(Note: The number of spacers used may vary. You may not need to you use any or all of the Spacers.)* (3) Insert two (G) Bolt – Hex Head 1/4" x 2" with two (H) Washers – Flat 1/4" through the slots in the (A) Base Plate, (I) and (R) Spacers *(if applicable)*, and (J) Fender Washer and thread them into the (F) Rivet Nut. Adjust the Tote Slide Bracket left or right to move into desired position. (4) Tighten bolts securely, but do not overtighten.
- 10 Place the Tote into the Tote Slide Bracket to make sure the Tote slides in and out of the vehicle properly. If necessary, adjust the (P) Adjustable Feet to raise or lower the Tote Slide Bracket.

Safety Instructions:

Warning: Make sure the Tote lid is closed and latched and the Tote and Tote Slide Bracket are secured in the vehicle according to the installation instructions while the vehicle is moving. Do not store explosives or hazardous materials in the Tote. Do not place loaded guns in the Tote. For further instructions refer to the vehicle owners manual or contact DU-HA, Inc.

