



**2000-2004 FORD SUPER DUTY 4WD
REAR LIFT FOR 6" F-250 W/O FACTORY OVER LOAD
LEAF FTS22088 REAR LIFT KIT**

PARTS LIST:

Qua	Part #	Description
	FTS22088	Rear Kit 00-04 SD
2	FTBK4	Lift Block
4	FT728U	U-Bolt
1	FT58H	U-Bolt Hardware
1	FTS419	Carrier Shim Kit
1	FT22088i	Instruction Sheet

Tool List: (Not Included)

- Floor Jack
- Jack Stands
- Assorted Metric and S.A.E Sockets & Allen Wrenches

READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION!

INSTRUCTIONS:

1. Disconnect the negative terminal on the battery. Jack up the rear end of the vehicle and support the frame rails with jack stands. Supporting the rear differential remove and discard the rear shocks and u-bolts. Lower the axle down slowly. Use care not to over extend the brake hose.
NEVER WORK UNDER AN UNSUPPORTED VEHICLE!
2. Locate and install the rear lift blocks, the factory block will be positioned on top of the new Fabtech block, with the short center pin of both blocks facing down, to the axle. The short end of the blocks should face to the front of the vehicle. Using the supplied u-bolts, nuts, and washers align axle, lift blocks, and springs and torque to U-Bolts to 90lbs
3. Install Fabtech shock part number FTS7266 (not included) with the factory hardware and torque bolts to 65lbs.
4. Install FTS419 Shim Kit per the instructions in the FTS419 box.
5. Recheck all bolts for proper torque. Recheck brake hoses and lines for proper clearances.
6. Install tires and wheels and torque lug nuts to wheel manufacturers specifications. Turn front tires left to right and check for appropriate tire clearance.
7. Check front-end alignment and set to factory specifications. Readjust headlights.
8. Check the front-end alignment and set to the factory specifications.