

INSTALLATION INSTRUCTIONS

PART No. FB23027, FB23028

Jeep® TJ Wrangler 1997-2006
Rock Slider – With & Without Tube Step



FB23027 shown



FB23028 shown



FB23028 shown

REQUIRED



REQUIRED TOOLS

16mm Socket
 17mm Socket
 6mm Allen
 Drill
 3/8" Drill Bit

KIT CONTAINS

M10 Stainless Flat Washer
 M10 Stainless Nylon Hex Nut
 M10 Stainless Countersunk Screw

QTY

10
 10
 10

- 1) **REMOVE YOUR OEM SIDE STEPS OR SLIDERS**
 Begin by removing your factory steps or sliders (if equipped).
- 2) **REMOVE FACTORY HARDWARE AND LIFT BODY**
 Remove the three bolts holding the body to the frame. Use a 16mm socket to remove these bolts.



INSTALLATION INSTRUCTIONS

PART No. FB23027, FB23028

Jeep® TJ Wrangler 1997-2006
Rock Slider – With & Without Tube Step



In the approximate location shown above, use a jack to lift your body away from the frame. **You only need to lift a small distance to allow enough room to slide the new rock slider in place.**



Lower your jack to bring the body back down on the frame.

4) **DRILL YOUR JEEP!**

Open your door and pull back the carpet under the door sill. Ensure there is nothing in the way when you drill into this area from the outside.

3) **INSTALL YOUR NEW ROCK SLIDERS**

Slide the slotted ends of the slider up between the frame and body mount. Ensure your slider is correctly spaced front and back on your Jeep, and flush with your Jeep's body.

Insert your OEM bolts and start threading them to ensure the slider is correctly positioned around the bolts. **DO NOT TORQUE THESE DOWN YET.**

INSTALLATION INSTRUCTIONS

PART No. FB23027, FB23028

Jeep® TJ Wrangler 1997-2006
Rock Slider – With & Without Tube Step



Using your rock sliders as a guide, drill a pilot hole in the center of each hole. Using a 3/8" drill bit, enlarge the pilot holes for the supplied hardware.



Using some silicon or paint, touch up the sheet metal you just drilled through to prevent rust. We recommend using a Q-tip for application.



Insert the M10 bolts. Using a 6mm allen and 17mm socket, tighten each bolt from inside your Jeep. The front bolt will be accessed from your fender well.



You may now finish tightening your body mount bolts.

5) RINSE AND REPEAT!

Repeat these steps for the opposite side of your Jeep.

6) HIT THE TRAILS AND ENJOY YOUR NEW ROCK SLIDERS!