




LoBoy Electric Fan


118 Puller / 119 Pusher

Installation Instructions



Puller Mode Mounting Instructions (see diagram "A")

1. Position the electric fan against the radiator, and mark mounting hole locations.
2. Pass a small Phillips screwdriver through the marked holes, carefully spreading the fins to allow easy passage for the nylon bolts. Fit the bolts to the mounting tabs, and pass the bolts through the shroud holes in the radiator.
3. Push on the speed nuts until they are snug.
4. Cut off the end of the mounting bolts, leaving 1/4" remaining.



Pusher Mode Through Core Mounting Instructions

Follow the instructions above, except mount fan on the front side of the radiator

Note: Some vehicles have a/c condensers or transmission coolers mounted in front of the radiator. Modifications may be necessary to accommodate the fan.

Wiring Instructions

Important: Puller fans:
Red wire is positive (+)
Black wire is negative (-)

Important: Pusher fans:
Black wire is positive (+)
Red wire is negative (-)

NOTE: Accessories such as relay kits and temperature control kits are available for this product! See www.flex-a-lite.com for details.

Important: Disconnect the battery prior to wiring this product.

Direct Connect: **(Fan will operate when the ignition is "on")**

1. Attach the positive fan motor wire to a 12 V positive ignition controlled source (example - fuse box). We recommend the use of a 30 Amp in-line fuse (not included) for each fan.
2. Attach the negative fan motor wire to a suitable ground. Note: Connect directly to battery negative terminal if possible.
3. Reconnect the battery.