




**INSTALLATION INSTRUCTIONS
CAT BACK SINGLE REAR STAINLESS EXHAUST
WITH TURNDOWN TAILPIPE FOR MAXIMUM CLEARANCE
TOYOTA FJ CRUISER 4.0L 4WD 4DR
PART # 618809**




ITEM	PART #	QUANTITY	DESCRIPTION
A	1062-700852S	1	2½" Stainless Headpipe w/GP-532 flange and welded hangers
B	11220S	1	Superflow Stainless Muffler
C	1063-700853S	1	2½" Stainless Overaxle tailpipe w/welded hanger
D	1399-701125S	1	2½" Stainless Exit pipe w/welded hanger
E	5757	3	2 ½" Clamp
F	BO-1036	1	Bolt Kit for Headpipe

CAREFULLY READ INSTRUCTIONS BEFORE STARTING INSTALLATION.

When installing this exhaust system make sure to use proper safety precautions. Use jack stands when working under the vehicle, set parking brake, block tires and use safety glasses and gloves. Allow exhaust to cool before attempting installation. Severe injury or burns could occur if safety measures are not taken.

SUGGESTED TOOLS: 1/2", 9/16" 15 mm Wrench & Socket, WD-40, Hacksaw, Jack Stand

Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual.



1. To remove the stock exhaust remove it from the 2-bolt flange located in front of the stock muffer. Disengage the welded hangers using WD-40 from the OEM rubber grommets. Do not damage or remove the rubber grommets as you will re-use them to mount your new system. Now, cut off tailpipe and remove exhaust.



4. Install the overaxle tailpipe #C into the muffer 1 1/2"-2" secure with clamp #E. DO NOT TIGHTEN. Insert welded hanger into rubber grommet.



2. Install head pipe #A onto your existing stock front pipe and attach with hardware kit #F. DO NOT TIGHTEN. Insert welded hangers into rubber grommets.



5. Next, install the exit pipe #D. onto overaxle pipe. Use clamp #E to secure to the tailpipes. DO NOT TIGHTEN. Insert welded hanger into rubber grommet.



3. Install muffer #B onto head pipe 1 1/2"-2" with the louvers facing towards the converter. Use a jack stand to support the muffer. Use clamp #E to secure the muffer to the headpipe. DO NOT TIGHTEN.



6. Check for all proper clearance and begin to tighten all clamps starting from the front of the vehicle. Before starting the engine be sure there is a 1" clearance from all exhaust parts.

GIBSON EXHAUST systems are designed on a factory stock vehicle. Any aftermarket products installed could increase the sound levels of this Exhaust. **Make sure there is a 1" clearance from ALL rubber brake lines, shock boots, fuel lines, tires, etc to prevent heat related damage or fire.**