

# GIBSON

## PERFORMANCE EXHAUST

1270 Webb Circle, Corona, CA 92879

T 951.372.1220


F 951.372.1233

### Suggested Tools:

1/2", 9/16", 15mm Socket & Wrench,  
WD-40, Jack Stand, Hacksaw

## Installation Manual: PN- 66564 Dual Sport Stainless Exhaust System

Vehicle Info: 2009 Dodge Ram 1500 5.7L Hemi 2wd, Crew Cab, Short Bed



Part Letter	QTY	Part #	Description
A	1	1345-701079S	3" Stainless Head Pipe
B	1	11235S	Superflow CFT Stainless Muffler
C	1	1363-701083S	2 1/4" Pass. side SS Tailpipe W/ Hangers
D	1	1364-701084S	2 1/4" Driver side SS Tailpipe W/ Hangers
E	2	500553	4" Stainless Tip
F	2	OHD300	3" Clamp
G	2	5756	2 1/4" Clamp

When installing this exhaust system allow use of proper safety precautions. Use jack stands when under the truck, set parking brake, block tires and use safety glasses and gloves. Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual. **DO NOT WORK WITH HOT PIPES!**

Step 1



To remove the stock exhaust, remove your factory exit pipes. Next, remove your tailpipes by unbolting them from the back of your stock muffler. Remove your factory muffler from the clamp in front of it. Use WD-40 to aid in removal of factory grommet that will be re-used.

Step 2



Install head pipe # A onto your existing stock front pipe and attach with clamp #F Do not tighten. Insert welded hanger into rubber grommet.

Step 3




Install muffler #B onto head pipe #A 1 1/2"-2". Use a jack stand to support the muffler. Use clamp #F to secure the muffler to the head pipe. Do not tighten.

Step 4



Install the passenger side overaxle tailpipe # C to the muffler 1 1/2"-2". Use clamp #G to secure tailpipe to muffler. Do not tighten. Insert welded hangers into rubber grommets.

Step 5



Install drivers side overaxle tailpipe #D into the muffler. Use clamp #G to secure. Do not tighten. Insert welded hangers into rubber grommets.

Step 1



Attach Stainless Steel tips. When you have everything in place, firmly tighten all bolts and clamp down securely. Use stainless steel cleaner and a Scotch Brite pad weekly to prevent tip from discoloration. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.

### IMPORTANT:

Make sure there is a 1" clearance from ALL rubber brake lines, shock boots, fuel lines, tires, and etc. to prevent heat related damage or fire.

Gibson Exhaust systems are designed on a factory stock vehicle. Any aftermarket products installed could increase the sound levels of this Exhaust.