



## GT9 Installation Hub – Models 10-5506, 20-5506

### Parts List:

Hub (1)  
Column wire (1)  
Ground wire (1)  
Ground wire screw (1)  
Wheel screws (9)  
Allen wrench (1)



### FITMENT:

<b>GM Autos</b>	1969-93	Chevrolet, Buick, Oldsmobile, Pontiac All Models (except Corvette, Sprint Spectrum, Nova 86-88, 1988-on Lemans)
<b>GM Trucks</b>	1974-94	Chevrolet/GMC Truck & SUV All Models (including 1968-88 El Camino)
<b>JEEP</b>	1976-95	All Models
	1974-75	Cherokee, Wagoneer, Pick-up
Custom Columns	IDIDIT All GM Columns	

### NOTICE

**Airbag equipped vehicles:** GT Performance Products steering wheels and hubs are **not** designed for use on Airbag equipped vehicles. **Due to Safety and Legal reasons**, we do **not** recommend changing, altering or removing the airbag from any vehicle.

### PRE-INSTALLATION INSTRUCTIONS

- A) **Read all instructions completely prior to installation process!**
- B) Align wheels on vehicle straight ahead and disconnect battery.
- C) **Removal of Original or Custom Steering Wheel:** Refer to shop manual for your vehicle or manufacturer of custom steering wheel. **Note:** A steering wheel or gear puller may be required.

### INSTALLATION INSTRUCTIONS

- 1) Once original wheel is removed from column, remove wire from steering column and replace with column wire supplied. (Push down and twist counter-clockwise to remove and reverse to install new column wire).
- 2) Install ground wire to hub as shown in photo A.
- 3) Note **“top”** marking on hub (2 vertical dimples next to one of the (9) nine holes which indicates “top”). Position hub onto shaft, carefully routing wire thru hub as shown in photo A.

Photo A



- 4) Install shaft nut and tighten.

### TORQUE REQUIREMENTS

Shaft nut: 25 / 30 ft. lbs.

- 5) Install wheel onto hub and tighten the (9) wheel screws. **CAUTION:** Do not over tighten mounting screws; this will cause damage to the hub.
- 6) Connect wires to bottom of horn button and carefully push horn button into hub flange. (Photo B) **Note:** If necessary, slightly wet the O-ring to ease installation.

Photo B



- 7) Reconnect battery and test operation of horn and turn signal canceling.

**NOTE:** **TO REMOVE HORN BUTTON:** Insert small, non-marring plastic blade, or screw driver between notch on bottom of horn button and wheel surface and carefully pry to release.