



PART # 89410, 89416 & 89418 INSTRUCTION SHEET FORD BRONCO 1966-77 302W V-8 4WD ONLY

CAUTION! This is a custom designed exhaust header system, designed for this particular application (s). Do not bend, bang, cut, dent, drill or heat any portion of this header! Any alteration other than those suggested in this instruction sheet will void the Hedman Lifetime Guarantee!
To prevent leaks, install your headers using Hedman Hedders exhaust gaskets ONLY and a spray copper gasket sealant.

BEFORE STARTING INSTALLATION:

It is necessary to raise the vehicle at least 36 inches from the ground. A floor hoist is recommended, if not available, use a hydraulic floor jack with jack stands. **DO NOT USE A BUMPER JACK!**

WARNING! Breaking in an engine with ceramic-coated headers **WILL** result in damage to the coating and will **VOID** all warranties. Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. Hedman Hedders recommends using a cast-iron exhaust manifold or an old header to break in new engines to avoid coating damage.

INSTALLATION INSTRUCTIONS:

1. Disconnect the battery, remove spark plugs (Number Wires) and oil dipstick tube.
2. Remove stock head pipes and exhaust manifolds.

LEFT SIDE:

1. Unbolt front drive shaft at U-joint and push aside. Be careful not to drop bearing cups!
2. On standard transmissions, remove clutch linkage and bracket from block. Install header from bottom of engine and with gasket in place, start all header bolts and tighten evenly.
3. Replace clutch cross shaft assembly and drive shaft. Re-route brake or fuel lines for adequate clearance. Re-route return spring for clutch.

RIGHT SIDE:

1. Install header from top or bottom of the engine and with gasket place. Start all header bolts and tighten evenly.
2. Replace oil dipstick tube and spark plugs.
3. Make sure all hoses , brakes, fuel lines and electrical wiring have sufficient clearance.
4. Install reducers and hook up headers to your exhaust system.
5. Re-connect battery.
6. Start engine, test drive vehicle, allowing engine to gain normal operating temperature. Check for leaks and new or unusual noises. After test drive, re-tighten all header bolts.


ENJOY YOUR HEADERS WHILE COMBINING INCREASED FUEL ECONOMY WITH BETTER PERFORMANCE.

SPECIAL INSTRUCTIONS!

After installing your headers it is very important that your exhaust system be suspended properly. As indicated in the drawing below you must place hangers as close to the header collector as possible. Rubber hangers should be used to allow the front of the system to flex with the engine torque. A hanger is needed before and after the muffler (s). When your exhaust system is unbolted from the header collector, it should remain suspended all by itself. Your Headers Are Not designed to support your exhaust system. Failure to follow these instructions will most likely result in cracks around the area where your primary tubes and collector are welded together, and will nullify your "Lifetime Guarantee".

DO NOT WRAP YOUR NEW HEADERS!

The use of thermal wraps will drastically shorten the life of your Headers, and will void the Hedman "Lifetime Guarantee".



Affix E.O. Sticker Next to Engine Specification Sticker Located on Firewall, Radiator Support, Air Cleaner, or Fender Panel in Engine Compartment.

WARNING: Not applicable or intended for street or highway use. Legal only for racing vehicles which may never be used upon a public highway.