

1. Position Clip onto backside of Bracket, with larger end in notch at top of Bracket.
2. With tongue of Bracket facing out & downwards, enclose lap belt between the two parts by snapping smaller end of Clip into hole of Bracket.
3. Slip the shoulder strap under the tongue of the Bracket & slide adjuster along both belts until comfortable (no more than 3" from seatbelt buckle).