




INSTALLATION INSTRUCTIONS

7642 Rear Stabilizer Bar

Ford E-150 Van

Thank you for purchasing a quality Hellwig Product.

PLEASE READ THIS INSTRUCTION SHEET COMPLETELY BEFORE STARTING YOUR INSTALLATION



TORQUE TABLE





BOLT SIZE: 3/8" = 20-30 ft. lbs. - 7/16" = 35-45 ft. lbs. - 1/2" = 50-70 ft. lbs. - 9/16" = 70-90 ft. lbs.

SAFETY: BEFORE STARTING YOUR INSTALLATION, BE SURE TO SET PARKING BRAKE AND CHOCK TIRES.

NOTE: TO EASE INSTALLATION AND TO PROPERLY ADJUST BAR, THE WEIGHT OF THE VEHICLE MUST BE ON THE SUSPENSION, AS IF DRIVING DOWN THE ROAD. DO NOT RAISE VEHICLE BY FRAME.

NOTE: THIS KIT INCLUDES LOCK NUTS WHICH REQUIRE TIGHTENING WITH A WRENCH AFTER BEING STARTED BY HAND.

Hellwig PRODUCTS



1. Place U-bolts over the axle tubes as shown in photos (2) and (3).
2. Lubricate D-bushings and place on flat areas of the bar to line up with the U-bolts.
3. Place saddle brackets over the legs of the U-bolts and attach sway bar to axle using the U-plates and 1/2" locknuts and flat washers. See photos (2) & (3). **Leave loose for adjustment later.**
4. Attach end links to angle bracket and sway bar as shown in photo (4). Rotate sway bar into position and align upper hole in angle bracket with existing hole in frame as shown in photo (4). Make sure that end links are oriented as shown in photo and not at a severe angle. Due to model variations a 1/2" diameter hole may need to be drilled in the frame to allow correct alignment of bracket. See photo (5). Some models may have an existing hole which will line up with the hole in the angle bracket that can be enlarged to 1/2" diameter. Others will not have a hole in the correct location and will require drilling a new 1/2" diameter hole. **Make sure to protect the fuel tank and brake, fuel and electrical lines before performing any drilling on frame rail. Confirm location of hole BEFORE drilling any holes.**



5. Attach angle bracket to frame rail by locating the welded bolt/plate assembly on the inside of frame rail and attaching angle bracket using 1/2" locknut and washer. **Leave loose for adjustment later.**
6. Attach J-bolts to frame and angle bracket as shown in photos (6) & (7) using thick washer and locknut. **Leave loose for adjustment later.**
7. Align sway bar for best fit and end link orientation.
8. Tighten 1/2" fastener holding the angle bracket to frame rail to 50 ft-lb.
9. Tighten J-bolt to 20-25 ft-lb.
10. Tighten Locknuts on U-bolts to 35 ft-lb.
11. Tighten end links until bushings begin to bulge slightly. **DO NOT OVERTIGHTEN.**
12. Recheck your installation, looking for clearance on any undercarriage components, such as gas lines, exhaust pipes, brake lines, wiring, differential cover, etc.
13. Drive vehicle for a few miles, then recheck for position and tightness, readjust and retorque as needed. Then recheck your installation after one week of driving and every thirty (30) days thereafter.