



P/N 2214HKR (painted) & 2214-1HKR(ceramic) SUPER COMPETITION FULL LENGTH HEADERS 1962-67 Chevy II / Nova (265-400) Fenderwell Exit

NOTE: Will not fit convertible models.

NOTE: Will fit with angle plug heads.

NOTE: Will not fit with heater.

Thank you for making HOOKER HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled HOOKER to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your hooker exhaust system.

WARNING! Breaking in an engine with ceramic-coated headers WILL result in damage to the coating and will VOID all warranties. Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. HOOKER recommends using a cast-iron exhaust manifold or an old header to break in new engines to avoid coating damage.

BEFORE STARTING

Your vehicle must be raised a minimum of 36 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure. **CAUTION! YOUR CAR SHOULD NOT BE SUPPORTED ON A BUMPER JACK.**

NOTE: Using an air chisel or cutting torch, remove the panel just behind the shock tower on both left and right sides (**Figure A**).

INSTALLATION PROCEDURE – PLEASE READ CAREFULLY

LEFT SIDE:

1. Disconnect the battery to prevent electrical system damage.
2. Remove the stock exhaust manifold, spark plugs, and alternator.
3. Work the header down through the fenderwell and into position.
4. Position the gasket and start all bolts (most restricted first).
5. Tighten all bolts (most restricted first).
6. Models with the generator/alternator mounted on the left side require Hooker generator/alternator mounting bracket (included in accessory pack). See **Figure B**.
7. Replace spark plugs.

RIGHT SIDE:

1. Remove the exhaust manifold and spark plugs.
2. Work the header down through the fenderwell and into position.
3. Position the gasket and start all bolts (most restricted first).
4. Tighten all bolts (most restricted first).
5. Replace the spark plugs.
6. To connect to the exhaust system, purchase Hooker reducer kit 11030HKR.

NOTE: A dual exhaust system can be using Hooker Competition Turbos #21005HKR, or 21006HKR and a universal tailpipe.

7. Connect the battery, start the engine, and check for leaks. Be sure all brake lines, fuel lines, transmission cooler lines, and electrical wires have sufficient clearance. Reroute as necessary.
8. When finished, give your vehicle a test drive, checking carefully for any new noises. After several days of driving, retighten all bolts.




Figure A




Figure B