



1. Locate vehicle taillight wiring harness (A) behind the interior rear driver's side molded panel (Phillips screwdriver and metric socket or crescent wrench required for some installations). This harness will have the same connector ends as the Wiring Kit.
2. Disconnect vehicle taillight wiring harnesses. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Plug Wiring Kit (B) into the male and female harness plugs. Be sure the connectors are fully inserted with locking tabs in place.
5. On two piece models only, grease extension terminals and plug into the Wiring Kit.
6. Ground the white wire to a clean surface on the vehicle frame using a self tapping screw or use an existing bolt.
7. Route harness to the exterior of vehicle.
8. Plug completed wire harness into the trailer connector.
9. Test all functions with engine running to ensure proper operation.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.