



## #42115

1. Locate the vehicle factory taillight wiring harnesses behind the rear bumper. These harnesses should have the same connector ends as the Hopkins® Wiring Kit.
2. Disconnect both vehicle factory connectors by lifting up on the release tab located on top of each housing. One is located on the driver's side, one on the passenger side.
3. Plug the Hopkins® vehicle connector marked "Left Driver" (A) into the male and female factory plugs on the driver's side of the vehicle. Plug the connector marked "Right Passenger" (B) into the male and female factory plugs on the passenger side. Be sure the connectors are fully inserted with the locking tabs in place.
4. Apply grease to the 4-way flat extension (C)

### NOTE:

If your application came with a separate 4-flat extension, plug the extension into the Wiring Kit.


5. Clean dirt and rustproofing from an area on the frame channel, drill a 1/8" hole and attach the white ground wire (D) with the screw provided.
6. Plug completed wire harness into the trailer connector and test all functions to assure proper installation.
7. Secure excess wire to the vehicle with cable ties provided.

### TIPS:

Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.

A heavy duty flasher may be required to eliminate rapid flashing.

Always unplug boat trailer connector before backing trailer into the water.



## Trailer Hitch Wiring & Electrical