


## Trailer Hitch Wiring &amp; Electrical



1. Locate vehicle taillight wiring harnesses (A). These harnesses will have the same connector ends as the Wiring Kits. Locate connectors under tail lamp assemblies behind bumper on the extreme outside edges of the vehicle.
2. Disconnect vehicle taillight wiring harness. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Plug Wiring Kit (B and C) into the male and female harness plugs. Be sure the connectors are fully inserted with locking tabs in place.
5. Plug completed wire harness (E) into the trailer connector.
6. Test all functions with engine running to ensure proper operation.

**TIPS:**

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.
- Converter maximum load – 2.1 amps. on left and right turn (one bulb on each side).