



1. Locate vehicle taillight wiring harness (A). This harness will have the same connector end as the Wiring Kit. Locate connector on passenger side of vehicle behind rear tire mud flap (D).
2. Disconnect vehicle taillight wiring harness. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Plug Wiring Kit (B) into the male and female harness plugs. Be sure the connectors are fully inserted with locking tabs in place.
5. On two piece models only, grease extension terminals and plug into the Wiring Kit.
6. Ground the white wire to a clean surface on the vehicle frame using a self tapping screw or use an existing bolt (C).
7. Plug completed wire harness into the trailer connector (E).
8. Test all functions with engine running to ensure proper operation.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

[Trailer Hitch Wiring & Electrical](#)