

PART #	DESCRIPTION
611030	05+ TACO/07-09 FJ SWAYBAR RELOCATION KIT

COMPONENTS INCLUDED	
(2) 157100 05+ TACO SWAYBAR RELOCATION BRACKET	
HARDWARE INCLUDED	
(4) 605100 3/8-16 X .750 BOLT	(4) 605133 3/8 SAE FLAT WASHER
TOOLS REQUIRED	
JACK JACK STANDS	TORQUE WRENCH 14MM SOCKET / WRENCH
TECH NOTES	
N/A	


**WARNING!**

**\*\* READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!**

**\*\* ICON VEHICLE DYNAMICS RECOMMENDS THAT YOU EXERCISE EXTREME CAUTION WHEN WORKING UNDER A VEHICLE THAT IS SUPPORTED WITH JACK STANDS.**

**\*\* ICON VEHICLE DYNAMICS RECOMMENDS ALL INSTALLATION TO BE PERFORMED BY A PROFESSIONAL SHOP/SERVICE TECHNICIAN. PRODUCT FAILURE CAUSED BY IMPROPER INSTALLATION WILL NOT BE COVERED UNDER ICON'S WARRANTY POLICY.**

**INSTALLATION**

1. Place the vehicle on flat and level ground, then chock the rear tires.
2. Disconnect the swaybar from the frame on both sides. Remove the (2) bolts using a 14mm socket/wrench and remove the bracket from the swaybar.
3. Install the (157100) swaybar relocation block. Using the supplied (605432, 605808) hardware, bolt the block to the frame [Torque to factory spec]. Make sure the block is positioned so that the new threaded holes are forward of the countersunk holes. Using the supplied (605100) bolts, (605133) washers and factory bracket, reinstall the swaybar in its new position. [Torque to 45 ft-lbs] [FIGURE 1 & 2]

FIG.1



FIG.2



**VERIFY ALL FASTENERS ARE PROPERLY TORQUED BEFORE DRIVING VEHICLE.**

**RETORQUE ALL NUTS, BOLTS AND LUGS AFTER 100 MILES AND PERIODICALLY THEREAFTER.**