

PART #	DESCRIPTION
95200	10-14 RAPTOR REAR 3.0 PB BYPASS SHOCKS

COMPONENTS INCLUDED	
(1) 194960D 10-14 RAPTOR 3.0 BYPASS (DRVR)	(1) 194960P 10-14 RAPTOR 3.0 BYPASS (PASS)
HARDWARE INCLUDED	
N/A	
TOOLS REQUIRED	
JACK JACK STANDS GRINDER W/ BARREL SANDER	TORQUE WRENCH 15MM SOCKET / WRENCH 18MM SOCKET / WRENCH
TECH NOTES	
<p>1. YOUR ICON SHOCK ASSEMBLIES COME FACTORY CHARGED TO 250 PSI. RELEASING NITROGEN PRESSURE MAY LEAD TO SHOCK MALFUNCTION AND REDUCED RIDE QUALITY. FAILURE CAUSED BY LOW NITROGEN PRESSURE IS NOT COVERED UNDER ICON'S WARRANTY POLICY.</p> <p>2. IF USING AFTERMARKET REAR LEAF SPRINGS, MINOR SANDING OF THE SHOCK MOUNT MAY BE NECESSARY TO ALLOW FOR THE FULL RANGE OF MOTION.</p>	



WARNING!
<p><b>** READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!</b></p> <p><b>** ICON VEHICLE DYNAMICS RECOMMENDS THAT YOU EXERCISE EXTREME CAUTION WHEN WORKING UNDER A VEHICLE THAT IS SUPPORTED WITH JACK STANDS.</b></p> <p><b>** ICON VEHICLE DYNAMICS RECOMMENDS ALL INSTALLATION TO BE PERFORMED BY A PROFESSIONAL SHOP/SERVICE TECHNICIAN. PRODUCT FAILURE CAUSED BY IMPROPER INSTALLATION WILL NOT BE COVERED UNDER ICON'S WARRANTY POLICY.</b></p>

## INSTALLATION

- Using a properly rated jack, raise the rear of the vehicle and support the frame rails with jack stands. Ensure the jack stands are secure and set properly before lowering the jack. NEVER WORK UNDER AN UNSUPPORTED VEHICLE. Remove the rear wheels.
- Using a jack, support the rear axle to relieve the tension from being at full extension.
- Remove the factory rear shocks using a 15mm and 18mm socket/wrench.

4. Minor sanding may be necessary to allow clearance for the top cap of the shock if using aftermarket leaf springs. If applicable, please refer to the attached diagram. Touch up any bare metal with spray paint to prevent corrosion. [FIGURE 1 - 3]

FIG.1




FIG.2



FIG.3




5. Install the ICON rear shocks using a 15mm and an 18mm socket/wrench. Note that the reservoir points away from the axle. [Torque to factory spec]

6. Ensure that the shock reservoir is clocked properly so that it won't make contact with the leaf spring. Check this with the heim spacers clocked towards the frame/leaf spring.

**VERIFY ALL FASTENERS ARE PROPERLY TORQUED BEFORE DRIVING VEHICLE.**

**RETORQUE ALL NUTS, BOLTS AND LUGS AFTER 100 MILES AND PERIODICALLY THEREAFTER.**



# ICON VEHICLE DYNAMICS

PERFORMANCE SUSPENSION SYSTEMS AND SHOCK ABSORBERS

## RAPTOR REAR BYPASS FIELD TUNING GUIDE

### NITROGEN SETTING

ICON SETTINGS: 220 PSI

### COMPRESSION TUBE 1 (SHORT)

ICON SETTINGS: ALL OUT

The short compression tube is designed to tune the “ride zone” specifically. The shocks piston is in this zone while at ride height, so any adjustments on this tube will be felt when street driving. This tube overlaps the long compression tube, therefore the long tube is used to add compression and it will affect the ride zone. The short tube can be used to counter any adjustments made to the long tube.

### COMPRESSION TUBE 2 (LONG)

ICON SETTINGS: (4) REVOLUTIONS OUT FROM CLOSED

The long compression tube affects the ride zone and the zone leading into the “bump zone”. This tube starts wide open; closing this tube off will start to affect the ride zone slightly and will start to stiffen the ride quality in the zone right after ride. If the vehicle is bottoming out easily, this tube will help increase the compression sooner and allow the shock to be slowing down more before it reaches the “bump zone”.

### REBOUND TUBE

ICON SETTINGS: (4) REVOLUTIONS OUT FROM CLOSED

Rebound control will greatly impair handling. Opening the rebound adjustment will cause the vehicle’s rear end to feel loose and can cause the vehicle’s rear end to “kick” or “buck”. Closing off the rebound adjustment can cause the vehicle to feel like the rear wheels are frozen and the vehicle will become harsh and choppy. The rear end will begin to “pack up” when off-roading and may kick/buck due to the shock bottoming out and not being able to return fast enough to catch the next bump.

### SHAFT

Keep an eye to make sure the shaft is clear from knicks/scratches. Small abrasions allow rust to form and eat away the shaft. Keep shafts smooth or damage to the seals can occur.


### MOLDED SHIN GUARD

Thick molded shin guard was designed specifically to protect the shaft, rod end, and bearing from pitting, scratches, and road debris. This is a wearable item and should be inspected after each offroad trip.

ICON RAPTOR SHIN GUARD REPLACEMENT, PART #191006

### HIGH QUALITY 3/4” BEARINGS (TOP/BOTTOM)

Commercial grade spherical bearings feature woven PTFE liners for smooth operation, but they are susceptible to dirt getting in and damaging the liner. Cleaning these bearings and preventing debris build up will prolong the life of these components.



### FIELD TUNING GUIDE

COMPRESSION TUBE 1	VALVE ON BOTTOM, THE SHORTER OF THE 2 TUBES. THIS VALVE HAS THE MOST FLOW AND WHEN OPEN ATTRIBUTES TO A SOFT RIDE. CAN BE LEFT MOSTLY OPEN UNLESS CARRYING A HEAVY LOAD. THE MORE ITS OPEN THE FASTER THE WHEEL CAN GO OVER AN OBSTACLE WITHOUT UPSETTING THE VEHICLE WHEN HIT AT SPEED. EFFECTIVE TO 65% OF TRAVEL
COMPRESSION TUBE 2	VALVE ON BOTTOM, THE LONGER OF THE 2 TUBES. THIS VALVE SLOWS DOWN THE WHEEL AS IT GETS CLOSER TO THE BUMP ZONE. WHEN DRIVING AGGRESSIVELY THIS VALVE KEEPS THE WHEEL FROM BLOWING THROUGH THE TRAVEL THE MORE IT IS CLOSED. EFFECTIVE TO 85% OF TRAVEL
REBOUND 2	VALVE ON TOP, INDEPENDENT TUBE. THIS VALVE CONTRIBUTES MOST TO THE OVERALL FEELING OF STABILITY. THE MORE ITS OPEN THE FASTER THE WHEEL CAN FOLLOW THE GROUND WHEN CYCLING QUICKLY. THE MORE ITS CLOSED THE MORE IT HOLDS THE CHASSIS DOWN. GENERALLY HAVING IT OPEN AS MUCH AS POSSIBLE WITHOUT MAKING IT TOO “FLOATY” IS BEST FOR OFF ROAD.

### RECOMMENDED SETTINGS

	GENERAL OFFROAD	HIGH SPEED WHOOPS	UNLOADED STREET	LOADED	TOWING
COMP 1	7 (OPEN)*	7 (OPEN)*	7 (OPEN)*	5	4
COMP 2	4	2 - 3	4	3	2
REBOUND	5	5.5 - 7.5	4	3	1.5 - 2

SETTINGS REFERENCE FULL TURNS OUT (COUNTERCLOCKWISE) FROM FULLY CLOSED (CLOCKWISE). (4 CLICKS PER TURN)

\*BYPASS VALVE WILL STOP CLICKING AT 6 FULL TURNS OUT, BUT WILL CONTINUE TO TURN ONE MORE REVOLUTION TO FULLY OPEN POSITION.

## 3.0 VS SERIES SHOCK & COILOVER TECHNICAL INFORMATION

### MAINTENANCE

ICON shock absorbers are a high quality rebuildable race style shock absorber designed for optimal performance. With a unit of this caliber on your vehicle, routine maintenance is required to keep them looking and operating in like new condition. Residual oil and assembly lube may be present at all seal paths from the factory out of the box and is considered normal. Pooling of oil however is not acceptable at any time and one should contact the ICON dealer where purchased.

**BELOW ARE GUIDELINES BASED ON HOW YOU USE YOUR VEHICLE BUT YOUR MILEAGE MAY VARY:**

#### **STREET USE:**

- Send in for factory servicing every 40,000 miles or if a leak develops, ride quality decreases, or they begin to make excessive noise.
- Remove any buildup of road salt, mud, or debris from shocks and coil springs anytime accrued
- Clean with mild soap and water with each oil change or anytime you notice build up.
- Wax the cylinders yearly with automotive wax to prevent corrosion.
- Check nitrogen pressure yearly. (252004 charge needle assembly available at any ICON distributor)
- Check bearings for excessive wear yearly.
- **DO NOT** apply any type of lube to the upper and lower bearings.

#### **STREET/DIRT:**

- Send in for factory servicing every 15,000 miles or if a leak develops, ride quality decreases, or they begin to make excessive noise.
- Clean with mild soap and water with each oil change, offroad trip, or anytime you notice build up.
- Wax the cylinders yearly with automotive wax to prevent corrosion.
- Check nitrogen pressure each dirt outing. (252004 charge needle assembly available at any ICON distributor)
- Check bearings for excessive wear yearly.
- **DO NOT** apply any type of lube to the upper and lower bearings.

#### **DIRT USE:**

- Send in for factory servicing every 1,000 miles.
- Check nitrogen pressure each outing. (252004 charge needle assembly available at any ICON distributor)
- Remove any buildup of mud or debris from shocks and coil springs after every outing.