



Part Number IS1550
1996-98 Honda Civic Ex, Hx

Contents Included:

- 1- Intake system (SR)
- 1- **3" Injen filter (#1014)**
- 1- 2.5"X3" Step hose (#3009)
- 1- 10" 10mm Vacuum hose (#3077)
- 1- 10mm 1/2' Sensor stub (#3077)
- 1- Power-Band (.040)(.312) (#4003)
- 1- Power-Band (.048)(.362) (#4004)
- 1- m6 Flange nut (#6002)
- 1- Fender washer (#6010)
- 1- m6 Vibra-mount (#6020)
- 1- 3 Page instruction



Figure 1



Note: Disconnect the battery terminals before starting this installation.

1. Remove the air intake box and the air intake duct leading to the throttle body. Remove the air temperature sensor from the box and vacuum lines.
2. Place the 2 1/2" side of the step hose onto the throttle body and use two clamps. Tighten the clamp on the throttle body at this point. See fig. 4

Warning! The car must be completely cold before removing any lines.

3. Remove the PCV pipe and heater hose line on the intake manifold and reroute the stock bypass hose on the throttle body to the heater hose port on the intake manifold. See figs. 2 and 3
4. Screw the vibra-mount on the strut tower top as seen in figure 4
5. Press the 10mm sensor stub into the 3/4" nipple on the intake. See fig. 5
6. Press the nipple end of the intake into the step hose on the throttle body and align the machined bracket on the intake to the vibra-mount stud use the m6 nut and washer. See fig. 6
7. Take the 3" Injen filter and place it over the end of the intake and tighten the clamp on the filter. See fig. 6
8. Press the air temperature control sensor into the 10mm stub placed in the 3/4" nipple. See fig. 5
9. Press one end of the 10"-10mm breather hose onto the valve cover port. The other end will go onto the 1/2" nipple of the intake. See figs. 1 and 6
10. Align the entire intake for best fit and clearance then continue to tighten all nuts, bolts and clamps. See fig. 1
11. Again, Check for clearance on the intake and reconnect the battery terminals.
12. Remove all tools and rags from the engine compartment before starting the engine. Congratulations! you have just completed this installation.