



Instruction P/N:PF8054



Vehicle Application:
 Make: **Dodge**
 Model: **RAM ECODiesel**
 Year: **2016**
 Engine: **3.0L Turbo Diesel**



Item	QTY.	P/N	Discription
A	1	W-PF8054	Intake Tube
B	1	1026	4" Dry Filter
C	1	3054	3-1/8" straight hose
D	1	3210	3-1/4" step hose
E	2	4004	#48 clamps
F	1	4005	#56 clamps
G	1	4006	#64 clamps
H	1	6020	M6 vibramount
I	3	6002	M6 nut
J	1	6010	Fender washer
K	1	M-20098	Bracket

TOOLS REQUIRED

- 10mm Ratchet & Socket
- 8mm nut drive
- Allen key
- Flat Blade Screwdriver
- Phillis Screwdriver

WARNING: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE SYSTEM, ENGINE AND COMPONENTS!!!
*Do not attempt to install the intake system while the engine is hot.
 Severe burn could result from touching hot engine components!

NOTE: This intake kit may not work on vehicles with the following aftermarket modifications.

- Aftermarket Intercooler piping
- Aftermarket intercooler
- Turbo upgrade
- Modified body panels
- Suspension & Chassis modifications



The SuperNano-Web filter media is a dry synthetic media that outperforms the competition. The media itself is a proprietary base blend of synthetics and cellulose. Cellulose fibers are larger than synthetic fibers, and have larger spaces between the fibers, causing contaminants to load in the depth of the media and plug the airflow path. This creates higher restriction levels and less capacity. The synthetic fibers in the SuperNano-Web media are submicron in diameter and have small interior fiber spaces, which result in more contaminants being captured on the surface of the media. This can help keep restriction levels low as the filter loads with dirt and containments



If you look at the picture to the left, you can see the Nano-fiber web on top of our base media. That web, or Super-Nano-Web as we like to call it, helps trap smaller particles and protect your engine.

To Clean your filter:

Carefully remove the filter from the housing. Once removed, wipe down the housing using a clean shop towel, being careful not to knock any dirt and/or debris in the air inlet. Your filters can be cleaned by carefully vacuuming the filter media from the dirty side, or by holding the filter with one hand and carefully blowing the filter media at a 45-degree angle from the clean side using low-pressure shop air (15-20 lbs. psi).


****IT IS IMPORTANT TO NOT USE ANY CLEANERS ON THE SUPERNANO-WEB MEDIA OR APPLY ANY OIL!!!***

NOTE: DISCONNECT BATTERY BEFORE INSTALLATION!!!

Instruction Manual P/N:PF8054



1. Stock intake system shown.




2. Loosen the clamp on the turbo housing. Disconnect MAF sensor.




7. Carefully un-clip upper half of airbox and remove.



3. Pull back the line that is attached to the lower air box assembly.




4. Lift up and remove the lower part of the air box assembly.



5. Locate the bolt on fender frame, loosen using 13mm wrench or socket. Save bolt for later install.



6. Now attach the vibramount to the threaded part of the bracket. Secure and tighten.



7. Now install the bracket, secure using bolt from previous step. This will be support bracket for the intake tube.



8. Now install the 3-1/8" straight hose with clamps to the turbo housing. Tighten clamp on turbo housing.



9. Loosen the 2 screws holding in the MAF sensor and remove the sensor.



10. Install the MAF sensor to the hose. ***Make sure the arrow is going in the direction towards the turbo.***



11. Rotate the MAF sensor and connect the harness. Tighten clamp on MAF sensor.




12. Install the step hose to the MAF sensor with clamps provided, tighten the clamp on MAF sensor.



13. Install the filter to the intake tube and tighten using 8mm nut driver.




14. Install intake into the vehicle and position the tube to step hose and the bracket to the vibramount.



15. Secure the bracket using provided M6 nut and fender washer.



16. Position for best fit and tighten the clamp on step hose using 8mm nut driver.



17. Tighten and secure the vibramount using 10mm socket or wrench.



Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose. **Note: Check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.**

Test Drive:

1. With the transmission in neutral or park and the parking brake engaged, start the engine. Listen for air leaks or odd noises. If air leaks are detected, secure hoses and connections. For any odd noises, inspect entire system for cause and adjust intake as needed. The Injen intake will function identically to the factory system but will be louder and more powerful.
2. Perform a road test. Listen for odd noises or rattles and fix as necessary.
3. If there are no issues, continue to enjoy your added performance from the Injen performance Intake kit.
4. Injen Technology recommends you periodically check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.

1. Upon completion of the installation, reconnect the negative battery terminal before you start the engine.
2. Align the entire intake system for the best possible fit. Once the intake has been properly fitted continue to tighten all nuts, bolts and clamps.
3. Periodically, recheck the alignment of the intake system and make sure there is proper clearance around and along the length of the intake. Failure to follow proper maintenance procedures may cause damage to the intake and will void the warranty.
4. Start the engine and listen carefully for any odd noises, rattles and/or air leaks prior to taking it for a test drive. If any problems arise go back and check the vacuum lines, hoses and clamps that maybe causing leaks or rattles and correct the problem.
5. Check the filter for excessive dirt build up. Congratulations! You have just completed the installation of the best intake system sold on the market. Enjoy the added power and performance of your new intake system.