



**HS3500/HS3600/HS5000
Heat Shield**

- 1-Universal heat shield / splash guard
- 3- Composite HS brackets (#4010)
- 3- 5/16" x 1/2" bolts (#6019)



figure 1

The HS-brackets are set over the press nuts and fastened with the 5/16" bolts.




figure 2

The filter is inserted into the shield and the clamp is over-lapped over the brackets.



figure 3

Once the filter is aligned continue to tighten the clamp over the intake.



figure 4

Check all 5/16" flange bolts for proper fit and adjustment.

- 1- Set the composite brackets in place and use the 5/16" flange bolts to hold the brackets in place. (See fig. 1)
- 2- Slip the filter into the shield opening and determine the best location for the HS-brackets by sliding the brackets up to the filter. Once the proper setting has been determined according to the size of the filter continue to tighten all bolts in place. (See fig. 2)
- 3- There are other ways to install the heat shield. Follow the first and second step without tightening the 5/16" bolts. Place the entire assembled filter over the intake system and tighten the clamp on the filter to the intake. (See figs. 3 and 4)
- 4- Check and tighten the 5/16" bolts previously placed into the press nuts. (See fig. 4)
- 5- Congratulations! You have now completed the installation.