

# SU Fit Hooks K118

# **Installation Instructions**

Before using the Mounting hooks, carefully read the installation instructions as well as the installation instructions for basic carrier systems, and follow all usage instructions. After reading the installation instructions, keep it in a safe place along with the installation instructions for basic carrier systems. If you are to give the mounting hooks to a third person, provide the installation instructions to ensure safe installation and usage.

# 

Install hooks correctly at specified positions according to the installation instructions herein and the installation instructions for the applicable carrier system. Installation positions of hooks depend on the vehicle type. If hooks are not installed at specified positions, the carrier may fall and cause accidents.


If inappropriate hooks are used, the carrier / attachment may fall and cause accidents. Before driving the vehicle, rock the stays and bars in all directions to ensure that there is no looseness. Retighten any loose knobs or bolts.

Do not use these hooks for attachments of non-specified types. The carrier may fall and cause accidents.

Observe the specified loading conditions. Failure to observe the loading condition may cause the carrier to break or loosen and fall, resulting in accidents.

For INNO dedicated ski & snowboard carriers, read the carrier installation instructions to determine proper mounting locations.

The SU Mounting hooks include the parts listed below. Verify that all of these parts are included in the carrier system you have purchased.




No.	Part	# of Part	Qty
1	Hook	231	4
2	Base	401	4

#### 

The specifications or external appearance of this product or any of the genuine spare parts may be changed for improvement without prior notification.

K118	Mounting Mo	ethod by `	Vehicle	Туре	EN
Manufacturer	Model	Туре	Year	Maximum loading capacity	Bikes
MINI	MINI	Hard Top	2002 -2008	80 lbs ( 36 kg) ( Load + Base rack + Attachments )	2

Maximum loading capacity is 36 kg ( 80 lbs) for this vehicle type.




## (Loosely attach hooks)


	Hook number	
Front hook	231	
Center hook	231	

Hook / base installation position

### Front








### 1 Note

- Base installation position for rear carrier is the same as front carrier.
- When knob is tightened, base moves slightly outward to the position illustrated above.

Front of vehicle

K118	Mounting Mo	ethod by `	Vehicle	Туре	EN
Manufacturer	Model	Туре	Year	Maximum loading capacity	Bikes
NISSAN	240SX	Hatchback	1989 -1994	120 lbs ( 55 kg) ( Load + Base rack + Attachments )	2


Maximum loading capacity is 55 kg (120 lbs) for this vehicle type.




## (Loosely attach hooks)

	Hook number
Front hook	231
Center hook	231

Hook / base installation position




Weather strip




### 🗊 Note


- Base installation position for rear carrier is the same as front carrier.
- When knob is tightened, base moves slightly outward to the position illustrated above.

<☐Front of vehicle




90092081184B-EN






## 231

Hook / base installation position



231

Weather strip



90092081185B-EN

Check out the collection of roof racks & cargo carriers we offer.

∠□Front of vehicle