

SU Fit Hooks K361

Installation Instructions

Before using the Mounting hooks, carefully read the installation instructions as well as the installation instructions for basic carrier systems, and follow all usage instructions. After reading the installation instructions, keep it in a safe place along with the installation instructions for basic carrier systems. If you are to give the mounting hooks to a third person, provide the installation instructions to ensure safe installation and usage.

! WARNING

Install hooks correctly at specified positions according to the installation instructions herein and the installation instructions for the applicable carrier system. Installation positions of hooks depend on the vehicle type. If hooks are not installed at specified positions, the carrier may fall and cause accidents.

If inappropriate hooks are used, the carrier / attachment may fall and cause accidents.

Before driving the vehicle, rock the stays and bars in all directions to ensure that there is no looseness. Retighten any loose knobs or bolts.


Do not use these hooks for attachments of non-specified types. The carrier may fall and cause accidents.

Observe the specified loading conditions.

Failure to observe the loading condition may cause the carrier to break or loosen and fall, resulting in accidents.

For INNO dedicated ski & snowboard carriers, read the carrier installation instructions to determine proper mounting locations.

The SU Mounting hooks include the parts listed below. Verify that all of these parts are included in the carrier system you have purchased.



No.	Part	# of Part	Qty
1	Hook	144S	4
2	Base	402	2
_	Dase	407	2

MOTE

The specifications or external appearance of this product or any of the genuine spare parts may be changed for improvement without prior notification.


K361 Mounting Method by Vehicle Type



Manufacturer	Model	Type	Year	Maximum loading capacity	Bikes
PONTIAC	G5	Coupe	2007 -2009	80 lbs (36 kg) (Load + Base rack + Attachments)	2

Maximum loading capacity is 36 kg (80 lbs) for this vehicle type.

Stay interior dimensions Front 37.2 inch/ 944 mm Rear 39.9 inch/ 988 mm




Install Bases

	Base number
Front base	407
Rear base	402

Mounting positions

Position the stays so that bolts align at specified mounting points.
 Gap between front




Bolt

Loosely attach hooks


	Hook number
Front hook	144S
Rear hook	144S

■ Hook / base installation position

Front



Rear



™ Note

 When knob is tightened, base moves slightly outward to the position illustrated above.

90092063612A-EN


K361 Mounting Method by Vehicle Type



Manufacturer	Model	Type	Year	Maximum loading capacity	Bikes
SATURN	ASTRA	5 door Hatchback	2008- 2010	120 lbs (55 kg) (Load + Base rack + Attachments)	2

Maximum loading capacity is 55 kg (120 lbs) for this vehicle type.

Stay interior dimensions Front 37.8 inch/ 960 mm Rear 37 inch/ 938 mm




(Install Bases

	Base number
Front base	407
Rear base	402

Mounting positions

Position the stays so that bolts align at specified mounting points.





Loosely attach hooks

	Hook number
Front hook	144S
Rear hook	144S

■ Hook / base installation position

Front





Note

 When knob is tightened, base moves slightly outward to the position illustrated above.


K361 Mounting Method by Vehicle Type



Manufacturer	Model	Type	Year	Maximum loading capacity	Bikes
FIAT	500	3 door	2012-	100 lbs (45 kg) (Load + Base rack + Attachments)	2

Maximum loading capacity is 45 kg (100 lbs) for this vehicle type.

Stay interior dimensions Front 38.1 inch/ 968 mm Rear 35.6 inch/ 906 mm




Install Bases

	Base number
Front base	402
Rear base	407

Mounting positions

 Position the stays so that bolts align at specified mounting points.




Loosely attach hooks


	Hook number
Front hook	144S
Center hook	144S

■ Hook / base installation position

Front



Rear



™ Note

 When knob is tightened, base moves slightly outward to the position illustrated above.

21092063614A-EN