

SU Fit Hooks K528

Installation Instructions

Before using the Mounting hooks, carefully read the installation instructions as well as the installation instructions for basic carrier systems, and follow all usage instructions. After reading the installation instructions, keep it in a safe place along with the installation instructions for basic carrier systems. If you are to give the mounting hooks to a third person, provide the installation instructions to ensure safe installation and usage.

Install hooks correctly at specified positions according to the installation instructions herein and the installation instructions for the applicable carrier system. Installation positions of hooks depend on the vehicle type. If hooks are not installed at specified positions, the carrier may fall and cause accidents.


If inappropriate hooks are used, the carrier / attachment may fall and cause accidents. Before driving the vehicle, rock the stays and bars in all directions to ensure that there is no looseness. Retighten any loose knobs or bolts.

Do not use these hooks for attachments of non-specified types. The carrier may fall and cause accidents.

Observe the specified loading conditions. Failure to observe the loading condition may cause the carrier to break or loosen and fall, resulting in accidents.


For INNO dedicated ski & snowboard carriers, read the carrier installation instructions to determine proper mounting locations.

The SU Mounting hooks include the parts listed below. Verify that all of these parts are included in the carrier system you have purchased.



No.	Part	# of Part	Qty
1	Hook	132	4
2	Base	401	4


The specifications or external appearance of this product or any of the genuine spare parts may be changed for improvement without prior notification.



90092055282A-EN

K528	Mounting M	ethod by	Vehicle	Туре	EN
Manufacturer	Model	Туре	Year	Maximum loading capacity	Bikes
FORD	FOCUS	4 door	2012-	120 lbs (56 kg) (Load + Base rack + Attachments)	2

Maximum loading capacity is 56 kg (120 lbs) for this vehicle type.




(Loosely attach hooks)


	Hook number
Front hook	132
Rear hook	132

Hook / base installation position

Front



Rear




🗊 Note

When knob is tightened, base moves slightly outward to the position illustrated above.

K528	Mounting M	ethod by	Vehicle	туре	EN
Manufacturer	Model	Туре	Year	Maximum loading capacity	Bikes
FORD	Ranger	4 door	2012-	120 lbs (55 kg) (Load + Base rack + Attachments)	2


Maximum loading capacity is 55 kg (120 lbs) for this vehicle type.



(Loosely attach hooks)

	Hook number
Front hook	132
Rear hook	132

Hook / base installation position Front




Note

When knob is tightened, base moves slightly outward to the position illustrated above.

K528	Mounting M	ethod by	Vehicle	Туре	EN
Manufacturer	Model	Туре	Year	Maximum loading capacity	Bikes
FORD	FOCUS	5 door	2012-	120 lbs (55 kg) (Load + Base rack + Attachments)	2

Maximum loading capacity is 55 kg (120 lbs) for this vehicle type.




(Loosely attach hooks)


	Hook number
Front hook	132
Rear hook	132

Hook / base installation position

Front



Rear



¹¹³²⁶¹⁰⁵²⁸⁵A-EN

Check out an excellent selection of roof racks & cargo carriers on our website.