

Made in America

Lifetime Guarantee



Thank you for purchasing this instrument from Intellitronix. We value our customers!

INSTALLATION GUIDE
LED Digital Transmission Temperature Gauge
Part Number: M9107

*** Always disconnect the battery *before* attempting any electrical work on your vehicle.***

KIT COMPONENTS

- ◇ **One (1) LED Gauge**
- ◇ **One (1) S8013 temperature sender**

WIRING INSTRUCTIONS

Note: Automotive circuit connectors are the preferred method of connecting wires. However, you may solder if you prefer.

*Ground - **Black*** Connect directly to an engine ground such as the engine block. For the most accurate readings, connect to the same ground as the sending unit.

*Power - **Red*** Connect to a switched +12V source such as the ignition switch.

*Dimmer - **Purple*** Connect to the parking lights to dim the LEDs 50% when the headlights are on. However, **do not** connect to the headlight rheostat control wire; the dimming feature will not work properly. Otherwise, connect to ground for permanent 100% brightness.

*Temperature - **Blue*** Connect to the output of the temperature sending unit.