

INSTALLATION INSTRUCTIONS Part Number: VF2002

This filter fits:

SEE CATALOG FOR CURRENT APPLICATIONS

K&N® Cabin Air Filters replace your vehicle's stock cabin filter with a reusable design that cleans and freshens incoming air. They are electrostatically charged to grab and hold dust particles. K&N[®] cabin air filters help control odors while they help capture most mold, mildew, fungus, spores, bacteria and germs. When they get dirty they can be cleaned and reused and best of all, they come with a 10 year/100,000 mile limited warranty.

When applicable, refer to owner's manual for manufactures installation/removal instructions. The following are helpful steps when replacing/servicing cabin air filter with K&N[®] cabin air filter.

- 1. Open glove box compartment. Fig. 1
- 2. Locate glove box stop feature. In most vehicles this is located on the right hand side of the glove box.
- 3. Remove fastener holding stop feature. Depending on your vehicle, the fastener may be a screw or a clip. Allow stop rod or cable to hang free. Fig. 2 & 3
- 4. Apply pressure to the sides of the glove box pushing into the center. This will allow the glove box to hang free allowing access to the cabin filter housing. On some models, there may be clips that need to be twisted and removed. Fig. 4
- 5. Locate cabin filter housing behind glove box compartment and unfasten clips on either side of cabin filter tray. Fig. 5
- 6. Remove cabin filter tray from cabin filter housing. Fig. 6
- 7. Remove dirty cabin filter. NOTE: Most trays have tabs built in. Use caution to ensure you do not bend or break these tabs. Remove any debris that might be present on cabin filter tray and inside the cabin filter housing. Fig. 7
- 8. Install K&N[®] Cabin Filter. Cabin filter will only fit in one direction. Once filter is installed correctly the filter will sit flush inside of tray. Fig. 8 & 9
- 9. Reinstall cabin filter tray into cabin housing, ensure tray is locked into place.
- 10. Reverse steps 1-4 to complete cabin filter installation. NOTE: With the cabin filter installed, clean an area on the housing and apply the K&N[®] Stop Decal. The decal will help notify others that this is a reusable cabin filter.





Fig.2



Fig.3



Fig.1

Fig.5



Fig.9



Fig.10



Fig.7





Fig.8

