



INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE KNFILTERS FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.

# INSTALLATION INSTRUCTIONS


**57-3092**  
**CHEVROLET**  
**2016-20 Camaro SS**  
**V8-6.2L**

**TOOLS NEEDED:**

- ratchet extension
- t50 socket
- flat blade screw driver
- phillips screw driver
- pliers

**PARTS LIST:**

| Description                      | Qty. | Part #  |
|----------------------------------|------|---------|
| A HOSE CLAMP #64 STAINLESS       | 2    | 08645   |
| B HOSE; 4" ID X 2" L REIN.       | 1    | 08761   |
| C INTAKE TUBE                    | 1    | 087319A |
| D VENT; 90°, 1/4NPT TO .600"     | 1    | 82633   |
| E HOSE CLAMP #72                 | 2    | 08671   |
| F HOSE; 4-1/2" ID X 3" L HUMP    | 1    | 08695   |
| G AIR FILTER                     | 1    | 33-5047 |
| H CAPLUG; 15/16" ID, 3/4" L, BLK | 1    | 08246   |
| I ADAPTOR; 1-1/8"OD QUICK        | 1    | 088012  |



**NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE TUBE, THROTTLE BODY AND ENGINE.**

**TO START:**

1. Turn off the ignition and disconnect the negative battery cable.  
**NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicles anti-theft code.**



2. Release the spring clamp and then disconnect the sound tube from the intake tube.



3. Disconnect the crank case vent hose from the intake tube.



4. Loosen the two hose clamps and then remove the intake tube from the vehicle.  
**NOTE: K&N Engineering, Inc., recommends that customers do not discard factory air intake.**



5. Remove the two bolts securing the sound drum to the engine.



6. Disconnect the clamps securing the sound tube then disconnect the front sound tube from the rear tube and the union.



7. Install the Provided cap onto the quick disconnect union provided.



8. Install the union/cap assembly into the rear sound tube.



9. Loosen the five screws securing the upper air filter housing and then remove the factory air filter.



10. Install the provided K&N® air filter. Reinstall the lid and secure with the factory screws.



11. Install the provided coupling hose (08761) onto the throttle body and secure with the provided hose clamp.



12. Install the provided hump coupler (08695) onto the mass air sensor and secure with the provided hose clamp.



13. Install the provided 90° quick disconnect fitting into the K&N® intake tube as shown.

**NOTE: Plastic NPT fittings are easy to cross thread. Install the vent fitting "hand" tight, then turn it two complete turns with a wrench.**



14. Install the K&N® intake tube into the hump coupler and then into the coupler at the throttle body, adjust the tube for best fit and then secure with the provided hose clamps.



15. Connect the crank case vent hose to the quick connect fitting in the K&N® intake tube.



16. Reconnect the vehicle's negative battery cable. Double check to make sure everything is tight and properly positioned before starting the vehicle.

17. The C.A.R.B. exemption sticker, (attached), must be visible under the hood so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

18. It will be necessary for all K&N® high flow intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.

#### ROAD TESTING:

1. Start the engine with the transmission in neutral or park, and the parking brake engaged. Listen for air leaks or odd noises. For air leaks secure hoses and connections. For odd noises, find cause and repair before proceeding. This kit will function identically to the factory system except for being louder and much more responsive.

2. Test drive the vehicle. Listen for odd noises or rattles and fix as necessary.

3. If road test is fine, you can now enjoy the added power and performance from your kit.

4. K&N Engineering, Inc., requires cleaning the intake system's air filter element every 100,000 miles. When used in dusty or off-road environments, our filters will require cleaning more often. We recommend that you visually inspect your filter once every 25,000 miles to determine if the screen is still visible. When the screen is no longer visible some place on the filter element, it is time to clean it. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.

**INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE KNFILTERS FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.**