Installation Instructions



For proper installation and best possible fit, please read all instructions BEFORE you begin.

Care and Cleaning

- · Wash only with mild soap and dry with a clean cloth.
- Every 3 months or 5000 miles check for loose hardware and tighten as necessary.

Congratulations!

You have purchased one of the many quality Lund® branded products offered by Lund International. We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment. We have made every effort to ensure that your product is top quality in terms of fit, durability, finish and ease of installation.

Recycle

The material that your product is made from can be recycled. Please also consider recycling the packaging that your product came in.



I-SHEET NUMBER: THX17

PRODUCT: **TERRAIN HX NERF BARS**APPLICATION: **19+ FORD RANGER**

PARTS INCLUDED	QTY
Driver Side	1
Passenger side	1
M10-X 25MM Hex Flanged Bolt	12

DO NOT USE IMPACT TOOLS



Front

Step 1: Locate the driver side step rail. The closed end will be closest to the bed of the truck.

Step 2: Remove any factory running boards or hardware and discard.





Step 3: Locate the three factory threaded mounting locations (Front, Center and Rear). There are 2 mount points (upper & lower) at each location. Remove the 6 upper and lower protective plugs. Carefully place the driver side step into place and loosely fasten using the supplied M10 x 25mm hardware.

Step 4: Next, tighten the three lower bolts first, then tighten the upper bolts.

Step 5: Repeat steps 2-4 for the passenger side.

