

Installation Instructions

I - Sheet Number 10753 Rev.A
LUND Part#318097



Running Board Bracket Kit

For proper installation and best possible fit, please read all instructions BEFORE you begin.


Important Safety Information



- To be used with Lund® branded products only.
- Do not stand on Lund running board or bracket while vehicle is in motion.
- Do not use the brackets as a jacking point for the vehicle.
- Do not use the bracket system or running boards to fasten cargo.
- Periodically check all components for tightness.
- Be sure to wear safety glasses while installing brackets.
- When using power tools, read and understand all operating instructions.

Contents

NOTE: Actual product may vary from illustration.




Passenger Rear Bracket



Driver Rear Bracket



Plastic retainer 10mm x6



Plastic retainer 12mm x2



5/16 Flange Nut x8



Passenger Front Bracket



Driver Front Bracket



10mm Flange Nut x6



12mm Flange Nut x2



10mm T-Bolt x2




10mm Offset Bolt Plate x4



12mm Bolt Plate x2


Tools Required



Ratchet and Extension



13mm - 15mm - 18mm Sockets



Wheel Chocks



Safety Glasses

Preparation Before Installation

- Park your vehicle in a clean, level location. Check to make sure the vehicle is in park, or for manual drive models, place the transmission in first gear. Engage the parking brake.
- Unpack the bracket kit and identify the parts according to the content descriptions.
- Cutting is required, and assistance is recommended.

Installation Steps



Start installation under the driver side of the vehicle. **NOTE:** To help determine the correct mounting holes to use, hold the front Bracket up in position against the floor panel and line up the Bracket with the correct holes. (Fig 1)

Driver side front Bracket installation:

Select (1) 10mm Offset Bolt Plate and (1) 10mm Plastic Retainer, (Fig. 2A). Partially thread the Retainer onto the Bolt Plate. Insert the Bolt Plate into the inner factory oval hole. Rotate the Bolt Plate so that the plate is across the slot. Thread the Retainer down until it is tight against the floor panel. The Retainer is designed to help hold the Bolt Plate in place during Bracket installation. Next, insert (1) 10mm T-Bolt with (1) 10mm Plastic Retainer into the outer oval hole in the floor panel next to the pinch weld as previously described. (Fig. 2B & 3)

Passenger side front Bracket installation:

Repeat the previous step for passenger side Bracket installation. (Fig. 4 & 5)




Fig. 1
Driver side front mounting location pictured




Fig. 2A
10mm Offset Bolt Plate



Fig. 2B
10mm T-Bolt for
driver and passenger
side outer location.




Fig. 3
Driver side pictured




Fig. 4
Passenger side front mounting location pictured




Fig. 5
10mm Offset Bolt Plate

Installation Steps




Hang the driver side Front Bracket from the bolts with (2) 10mm Flange Nuts. (Fig. 6). Do not tighten hardware at this time.



2

Fig. 6

Move to the rear location and remove the plastic cover on the floor panel. Release the plastic clips holding the lower plastic rocker panel cover to the bottom of the body. (Fig. 7)



3

Fig. 7



Locate the small round hole under the plastic rocker cover. Select (1) 10mm Offset Bolt Plate and (1) 10mm Plastic Retainer. (Fig. 8) Insert the Bolt Plate into the round hole and tighten Plastic Retainer against body. (Fig. 9 & 10)



Fig. 8




Fig. 9



Fig. 10

4

Installation Steps



Next, locate the large round hole in the floor panel. Insert (1) 12mm Bolt Plate into the large round hole and out the smaller hole toward the front. (Fig.11 & 12)



Fig. 12



Fig. 11

5



Next, Slide the driver side Rear Bracket under the plastic rocker cover and over the (2) Bolt Plates, (Fig. 13). Secure the Bracket to the outer 10mm Bolt Plate with (1) 10mm Flange Nut. Attach the Bracket to the Larger 12mm Bolt Plate with (1) 12mm Flange Nut. Do not tighten hardware at this time.



Fig. 13

6

Hold the plastic cover removed in **Step 8**, up in position. Trace the location of the rear Bracket onto the cover, (Fig. 14). Carefully cut the plastic cover to clear the Bracket, (Fig. 15A & 15B). **IMPORTANT:** Cut as little as possible from the cover. Do not cut off the mounting area for the factory hardware. Reinstall the plastic cover and all plastic clips holding the bottom of the rocker cover to the body panel.



Fig. 14



Fig. 15A




Fig. 15B

7

Installation Steps



Position the driver's side running board onto bracket and center on vehicle. Adjust Running Board to be parallel with side of vehicle. Install (4) 5/16" flange nuts (bolts are already installed on board).

Tighten all bracket hardware, position the board accordingly, and then tighten Running Board to brackets.

Repeat Steps 1 thru 8 for opposite side of vehicle. (Fig.16)



Fig. 16

8

Inspection After Installation

- Inspect all bolts and nuts for proper tightness.

Care and Cleaning

- Wash only with mild soap & dry with a clean cloth.
- Do not use cleaning solvents of any kind.

Congratulations!

You have purchased one of the many quality Lund[®] branded products offered by Lund International, Inc. We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment. We have made every effort to ensure that your product is top quality in terms of fit, durability, finish and ease of installation.

LUND[®]

