



Utility Shelving With Tote Bins 46x37x12 Assembly / Installation Instructions




■ Utility Shelving - 02C448KP




■ Bill of Materials

Qty	Description / Part #
1	LEFT AND RIGHT UPRIGHTS / 025367
1	FLOOR BRACE / 023058
12	PLASTIC BUCKET / 021471
4	SHELF / 021381




■ Assembly





■ Assembly

Attach Bottom Shelf as shown using;
(8) 1/4-20 x 3/4 Hex Head Screws
(8) 1/4-20 E-Stop Nuts







■ **Assembly**


Attach remaining Shelves as shown using;
(8) 1/4-20 x 3/4 Hex Head Screws
(8) 1/4-20 E-Stop
(PER SHELF)



■ Assembly



■ Plusnut Installation



USE DRILL STOP TO
PREVENT DAMAGING VEHICLE



**BEFORE DRILLING - CHECK
ALL MOUNTING LOCATIONS
TO PREVENT PENETRATING
GAS LINES, GAS TANKS, BRAKE
LINES, WIRING OR ANY OTHER
STRUCTURE OF VEHICLE**




The Plusnut® is pre-bulbed for easy installation

1



The Plusnut® is pre-assembled with hex cap and hex bolt.
Then it is inserted into a pre-drilled hole

2



As the bolt is tightened, the Plusnut® upsets
and provides outstanding
blind fastening holding power

3



C-500 tool tightens bolt thru hex head cap into Plusnut® A
ratchet, open-end or closed –end wrench can be used.


4




Fully upset Plusnut® provides
a reliable nut plate for fastening.

5

■ Plusnut Installation



**MOUNTING WITH PLUSNUT
(LIMITED SPACE UNDER VEHICLE)**



**MOUNTING THROUGH FLOOR
(WHERE SPACE PERMITS UNDER VEHICLE)**