



**PRODUCT: K751364 - 6" LIFT KIT  
07-12 GM 1500 PICKUP**

**PARTS LIST**

**QTY**

SPINDLE, CHEVY 3" LIFT, DRIVER	1
SPINDLE, CHEVY 3" LIFT, PASSENGER	1
FRONT STRUT SPACER	2
10mm X 1.25 FLANGE NUT	6
REAR STEEL TAPERED BLOCKS, 4"	2
U BOLT, 9/16-18 X 2.63 X 12.5, SQUARE	4
U-BOLT WASHER, 9/16	8
HI NUTS, 9/16-18	8
MAXTRAC SHOCK ABSORBER, 2900LL	2
ADEL CLAMP	4

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION, TO ENSURE ALL PARTS ARE PRESENT

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

**PRIOR TO INSTALLATION:**

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.
5. Jack up front of vehicle, place jack stands under frame, behind front suspension.

After removing parts from vehicle, save hardware for reinstallation

**IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHEN INSTALLING NEW SUSPENSION PARTS. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.**

## FRONT SPINDLES, BRAKE LINES, & STRUT SPACER LEVELING KIT

1. Remove brake caliper bolts at the spindle, do not allow caliper to hang from brake hose. Remove retainer bolt for brake rotor, then remove rotor.



2. Open up brake hose clamp on upper control arm and remove from bracket. Unbolt brake hose bracket from upper control arm, then unbolt abs wire bracket from the spindle.



3. Remove ABS sensor from spindle and put it safely out of the way. Remove through bolt for sway bar end link and linkage.



4. Unbolt unit bearing, remove and discard dust shield (will not be used). Unbolt tie rod from the spindle, then knock tie rod loose by hitting the side of the spindle, do not hit tie rod or threads!




5. Loosen the upper ball joint nut, loosen the lower ball joint nut and leave the nut loose on the end of the threads, then knock the upper ball joint loose by striking the spindle (do not hit the threads!)



6. Remove lower strut bolts, remove nuts at the top of the strut, then remove entire strut
7. Install Maxtrac strut spacer on the top of the strut, cut or shave off about 1/16<sup>th</sup> of an inch of the original strut bolts.




8. Reinstall strut, and tighten bolts on top of strut tower.
9. Support lower control arm and add pressure with a jack, then line up Maxtrac spindle with upper & lower ball joint, and loosely install nuts.



10. Tighten the upper ball joint nut, then tighten the lower ball joint nut.
11. Remove the ABS guide clip from the rear part of the upper control arm.
12. Remove lower half of the clip from ABS plug, and then remove clip from ABS wire.



13. Use the provided Adel Clamp and factory bolt to attach ABS wire to upper control arm.
14. Then run ABS wire under upper control arm and across the front of the spindle.
15. Attach ABS wire to Maxtrac spindle using the provided Adel Clamp and factory bolt that was previously attaching the bracket to the top of the stock spindle.




16. Unbolt brake line guide from the back side of upper control arm mount, then bend the tab on brake line bracket to a straight position.

17. Drill new hole approximately 1" below original hole, smaller than original hole, so the bolt can be self tapped in. Be sure to leave enough room for the alignment cam to fully cycle.



18. Zip tie ABS wire to the brake line.
19. Reinstall brake rotor and tighten retainer bolt, then reinstall brake caliper.
20. Carefully bend brake line elbow outward and up to allow slack in brake line.
21. Cycle spindle, at full droop, back and forth to ensure there is enough slack in the hose, and that the brake hose does not contact the lower arm or any other component.
22. Reinstall the tie rod and tighten the nut
23. Reinstall the sway bar end links and tighten.




## REAR LIFT BLOCKS, UBOLTS, SHOCK ABSORBER INSTALLATION

1. Place a floor jack under the differential and jack up the rear.
2. If you have jack stands, place them under the frame rails and lower
3. Remove tires and wheels.
4. Remove factory shock absorbers, retain factory hardware.
5. Remove factory ubolts, lower the axle using the floor jack.



6. Install lift block on factory spring pad with the angled part towards the front of the vehicle.
7. Use the floor jack to lift the rear axle, keeping the pin aligned, and install the new ubolts and hardware.



8. Reinstall stock or aftermarket shock absorbers.
9. Install wheels and tires, set vehicle on the ground.

Double check all fasteners before placing vehicle on the ground.  
Get the vehicle re-aligned as soon as possible.  
Re-torque all fasteners after 100 miles, and then at 500 miles.