

2016+ CAMARO SS INDUCTION HOSE

PARTS LIST AND INSTALLATION GUIDE



PARTS LIST

- 1 PC | SILICONE HOSE
- 1 PC | 20-32MM WORM-GEAR CLAMP
- 1 PC | 100-120MM WORM-GEAR CLAMP
- 1 PC | 110-130MM WORM-GEAR CLAMP
- 1 PC | CNC FITTING
- MOUNTING HARDWARE

TOOLS NEEDED

- FLATHEAD SCREWDRIVER
- DIAGONAL CUTTERS
- CHANNELLOCK PLIERS

INSTALLATION TIME **20 MINS**

INSTALL DIFFICULTY

DISCLAIMER

- Raise vehicle only on jack stands or on a vehicle lift.
- Allow vehicle to cool completely prior to attempting installation.
- Do not run the engine or drive the vehicle while overheating; serious damage can occur.
- Please dispose of any liquids properly.
- Mishimoto is not responsible for any vehicle damage or personal injury due to installation errors, misuse, or removal of Mishimoto products.
- Mishimoto suggests that a trained professional install [all Mishimoto products](#).

INSTALLATION INSTRUCTIONS

01. Separate the crankcase ventilation (CCV) hose from the intake hose. To disconnect this hose, depress the gray tab and pull the hose off the port.



02. Compress the clamp that secures the sound generator tube to the intake hose and separate the tube from the hose.



03. Loosen the clamps that secure the intake hose to the throttle body and the airbox. Then remove the intake hose from the vehicle.

04. Cut the clamp that secures the sound generator tube to the diaphragm under the throttle body. Then remove the hose from the diaphragm.



05. Locate the fitting and small worm-gear clamp included with your kit. Install the fitting to the Mishimoto induction hose and secure it with the clamp. (1x worm-gear clamp)



06. Locate the remaining hose clamps in your kit. Install one over each end of the induction hose. Then install the induction hose to the throttle body and the airbox. Tighten the clamps to secure the hose. (2x worm-gear clamps)

07. Install the CCV hose to the port on the induction hose. Simply push it on until it clicks.



Congrats! You just finished installing the 2016+ Camaro SS Induction Hose.

01