

# MSD IGNITION INSTALLATION INSTRUCTIONS

## MSD to GM Single Coil Harness PN 8877

**IMPORTANT:** Review the Ignition Control instructions before attempting the installation.

The MSD to GM 3-Terminal Coil Harness is designed to provide a splice-free and simple installation of an MSD Ignition Control to GM vehicles equipped with a 3-Terminal single connector Coil (Figure 1).

### MSD 6 and 7 Series Ignitions

All of the wires connect to the corresponding colored wires (Figure 2). MSD 7 Series Ignitions share the same color wires.

1. Disconnect the connector from the coil and connect it to the MSD PN 8877 Harness.
2. Connect the other end of the Harness to the Coil.
3. Connect the four wires of the Harness to the MSD Ignition Control.




Figure 1 GM 3-Terminal Coil.




Figure 2 Installation with an MSD 6 or 7 Series Ignition Control.

### Installation with an MSD Timing Control

The PN 8877 may still be used when adding an MSD Timing Control. Figure 3 shows a common installation.




Figure 3 Wiring in an MSD Timing Control with a 6 or 7 Series Ignition.

# MSD IGNITION INSTALLATION INSTRUCTIONS

## MSD 5 and Blaster Ignition

Note that the MSD 5 and Blaster Ignitions wire differently than the 6 and 7 Series Ignitions. The Red wire of the MSD 5 or Blaster Ignition connects to **both** the Harness Orange and Red wires (Figure 4).




Figure 4 Installation with an MSD 5 or Blaster Ignition.