

Please read and save these instructions. Read through this owner's manual carefully before using product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.



## COOLING SYSTEM FUNNEL

### UNPACKING

After unpacking unit, inspect carefully for any damage that may have occurred during transit. Check for loose, missing, or damaged parts. If any damage is observed, a shipping damage claim must be filed with carrier. Do not use Cooling System Funnel if broken, bent, cracked or damaged parts (including labels) are noted. Any Cooling System Funnel that appears damaged in any way, operates abnormally or is missing parts should be removed from service immediately. If you suspect that the Cooling System Funnel was subjected to a shock load (a load that was dropped suddenly, unexpectedly, etc.) immediately discontinue use until it has been checked by a factory authorized service center.



### ⚠ WARNING

The following safety information is provided as a guideline to help you operate your Cooling System Funnel under the safest possible conditions. Any tool or piece of equipment can be potentially dangerous to use when safety or safe handling instructions are not known or not followed. The following safety instructions are to provide the user with the information necessary for safe use and operation. Please read and retain these instructions for the continued safe use of your service system. Failure to follow instructions listed below may result in serious injury. In addition, make certain that anyone that uses the equipment understands and follows these safety instructions as well.

### Explanation of Safety Signal Words

**⚠ WARNING:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**⚠ CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**CAUTION:** Used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

**NOTES:** Provide clarity and helpful information.

Thank you very much for choosing an OEMTOOLS Product!

For future reference, please complete the owner's record below:

**Model:** \_\_\_\_\_ **Purchase Date:** \_\_\_\_\_

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it. This product is designed for certain applications only. OEMTOOLS cannot be responsible for issues arising from modification. We strongly recommend this product is not modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the product until you have first contacted OEMTOOLS to determine if it can or should be performed on the product.



## COOLING SYSTEM FUNNEL



### IMPORTANT INSTRUCTIONS AND SAFETY RULES

1. Know your tool. Read this manual carefully. Learn the tool's applications and limitations, as well as, potential hazards specific to it.
2. Keep work area clean and well lit. Cluttered or dark work areas invite accidents.
3. Keep children away. All children should be kept away from the work area. Never let a child handle a tool without strict adult supervision.
4. Do not operate this tool if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not attempt to operate.
5. Use safety equipment. Eye protection should be worn at all times when operating this tool. Use ANSI approved safety glasses. Everyday eyeglasses are NOT safety glasses. Dust mask, non-skid safety shoes, hard hat or hearing protection should be used in appropriate conditions.
6. Wear proper apparel. Loose clothing, gloves, neck-ties, rings, bracelets or other jewelry may present a potential hazard when operating this tool. Keep all apparel clear of the tool.
7. Don't overreach. Keep proper footing and balance at all times when operating this tool.
8. Check for damage. Check your tool regularly. If part of the tool is damaged it should be carefully inspected to make sure that it can perform its intended function correctly. If in doubt, the part should be repaired. Refer all servicing to a qualified technician. Consult your dealer for advice.
9. Store idle tools out of the reach of children and untrained persons. Tools may be dangerous in the hands of untrained users.
10. Maintain tools with care.
11. Keep tools dry and clean.
12. Do not use a damaged tool. Tag damaged tools "Do not use" until repaired.
13. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool may become hazardous when used on another tool.
14. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.
15. When servicing a tool, use only identical replacement parts. Use of unauthorized parts or failure to follow maintenance instructions may create a risk of injury.
16. Maintain a safe working environment. Keep the work area well lit. Make sure there is adequate surrounding workspace. Keep the work area free of obstructions, grease, oil, trash, and other debris. Do not use this product in a damp or wet location.
17. Maintain labels and nameplates on this product. These carry important information. If unreadable or missing, contact OEMTOOLS for a replacement.
18. Before use, read and understand all warnings, safety precautions, and instructions as outlined in the vehicle manufacturer's service manual. It is beyond the scope of this manual to properly describe the correct procedure and test data for each vehicle.
19. Always perform vehicle service in a properly ventilated area. Never run an engine without proper ventilation for its exhaust. Stop work and take necessary steps to improve ventilation in the work area if you develop momentary eye, nose, or throat irritation as this indicates inadequate ventilation.

### WARNING

Engine parts that are in motion and unexpected movement of a vehicle can injure or kill. When working near moving engine parts, wear snug fit clothing and keep hands and fingers away from moving parts. Keep hoses and tools clear of moving parts. Always stay clear of moving engine parts. Hoses and tools can be thrown through the air if not kept clear of moving engine parts. The unexpected movement of a vehicle can injure or kill. When working on vehicles always set the parking brake or block the wheels.

- Avoid accidental fire and/or explosion. Do not smoke near engine fuel and battery components.
- For safety purposes and the prevention of damage to expensive components it is advised that the user have an understanding of basic automotive repair and a working knowledge of automotive systems.
- We believe the information contained herein to be reliable. However, general technical information is given by us without charge and the user shall employ such information at his own discretion and risk. We assume no responsibility for results or damages incurred from the use of such information in whole or in part. Always refer to specific instructions and technical information supplied by vehicle manufacturer.
- Be alert for hot engine parts to avoid accidental burns.
- If you drove your car recently, fluids could be very hot. Allow at least 2 hours before you handle any fluids. Oil and Coolant burns are very dangerous.
- Never remove the cap from the radiator or expansion tank while the engine is at operating temperature.
- Always allow the engine to cool before removing the radiator cap or expansion tank cap. The cooling system is under pressure. Failure to allow the engine to cool before attempting to remove the cap could result in serious injuries.
- Does not misuse, over-pressurize, modify parts, or use worn and/or damaged parts.
- Do not use Cooling System Funnel for flammable or caustic fluids.

**NOTE:** The manufacturer declines any and all responsibility for damage to vehicles or components if said damage is the result of unskillful handling by the operator or of failure to observe the basic safety rules set forth in the instruction manual.

### WARNING

Used oil, antifreeze, brake fluid and transmission fluid contains chemical compounds that can be harmful to humans and other animals. When managed properly, used fluids may again be of beneficial use. Used may be blended and recycled as a heating or industrial fuel and also may be re-refined and made into new lubricants. Persons who perform maintenance on their own vehicles are responsible for managing the used fluids in a manner that is protective of human health and the environment and to follow all local laws and regulations concerning their disposal.



## COOLING SYSTEM FUNNEL

### **⚠ WARNING**

Read Rules for Safe Operation and Instructions Carefully.

#### **IMPORTANT SAFETY INSTRUCTIONS**

The warnings, precautions, and instructions discussed in this manual cannot cover all possible conditions and situations that may occur. The operator must understand that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

#### **DISPOSAL**

At the end of the useful life of the Cooling System Funnel, dispose of the components according to all state, federal and local regulations.

#### **PURPOSE**

The OEMTOOLS Cooling System Funnel provides a quick and easy way to fill automotive cooling systems while preventing spills and trapped air. Adapters and extensions are included to fit radiators or surge tanks on most domestic and import cars and light-trucks. The funnel incorporates a fluid stopper with vent to prevent excessive cooling system pressure build up while filling.

### **PRODUCT SPECIFICATIONS**

**Funnel Dimensions:** 6 1/2" x 8"

**Cooling System Adapters:** 5

#### **OPERATION:**

### **⚠ CAUTION**

1. This equipment is intended only for professional use by personnel trained in performing the service functions for which it is has been designed.
2. This equipment is designed for servicing a variety of vehicles in a safe, convenient manner. However, differences in vehicle makes and models may make it impossible to use this equipment as it is intended. Do not attempt to force the use of this equipment on an application for which it is not designed to perform.
3. The procedures documented in this manual are to serve as guidelines for the use of this equipment.
4. In addition to these guidelines, always follow the manufacturer's recommended procedures when servicing each unique vehicle.
5. The use of this equipment is simple and straightforward if you follow the instructions. However, always keep in mind that you are working with a system that may be under pressure, with fluid that is just waiting to be expelled. When operating this equipment, use common sense, and always stop to think before disconnecting a hose or other component.

#### **INSTRUCTIONS:**

### **⚠ WARNING**

Some vehicle manufacturers provide specific instructions to fill and bleed their cooling systems. It is important to understand and follow the vehicle manufacturer's instructions to prevent damage to components and possible injury.

1. Select the proper size cooling system adapter that fits your cooling system (compare to your cooling system cap).
2. Install cooling system adapter onto your radiator or coolant tank, making sure to get a positive seal.
3. Press the angled adapter, extension or funnel into cooling system adapter opening. If using the angled adapter or extension, it must be installed in the cooling system adapter before the funnel is installed. Install the funnel into the adapter or extensions, making sure all components are positively engaged to prevent leaks.
4. Any combination of angled adapters or extensions can be used to access hard to reach cooling systems.
5. Once assembled, funnel should be level and away from any moving parts.
6. Make sure fluid stopper is in the open or up position.
7. Pour fluid into funnel, filling the cooling system slowly so air can escape.
8. Fill system until funnel is approximately 1/3 full with coolant. Do not overfill funnel.
9. Start engine with funnel attached.

### **⚠ WARNING**

Do not increase engine speed above idle while waiting for the thermostat to open. Excessive RPM can cause fluid to overflow.

10. If fluid level should rise excessively, shut down the engine and wait for the fluid level to lower before restarting the engine.
11. Continue to add coolant to the funnel until the cooling system is completely filled.
12. When complete, if fluid remains inside funnel, squeeze and hold the large radiator hose while closing (down position) fluid stopper in funnel, then release hose. This will allow fluid to flow back into the radiator and prevent fluid spilling when removing funnel.
13. Remove the funnel and empty fluid into appropriate container by opening (raising) fluid stopper.
14. Remove extension or angled adapter along with the cooling system adapter, then reinstall radiator cooling system cap.


#### **MAINTENANCE:**

1. Always store the Cooling System Funnel in a well-protected area where it will not be exposed to inclement weather, corrosive vapors, abrasive dust, or any other harmful elements.
2. Keep the Cooling System Funnel clean for better and safer performance.



# COOLING SYSTEM FUNNEL

Figure	Description	Quantity
1	Funnel	1
2	Fluid Stopper with Vent	1
3	Angled Adapter	2
4	Extension Adapter	1
5	Standard Cap Cooling System Adapter	1
6	Small Cap Cooling System Adapter #1	1
7	Small Cap Cooling System Adapter #2	1
8	Threaded Cap Cooling System Adapter #1	1
9	Threaded Cap Cooling System Adapter #2	1



**NOTE:** Not all components of the Cooling System Funnel are replacement items, but are illustrated as a convenient reference for location and position in the assembly sequence.

Please read the following carefully.

OEMTOOLS and/or its distributors have provided the parts list and assembly diagram as a reference only. Neither OEMTOOLS and/or its distributors make any representation or warranty of any kind to the buyer and/or user of this tool that he or she is qualified to do any repairs or replace any parts of this product. OEMTOOLS and its distributors expressly state that all repairs or parts replacement should be done by certified or licensed technicians. The buyer assumes all risk and liability arising out of his or her repairs or parts replacement to the original production.