


Hardware included shown on right.

Tools required:

- #27 torx bit
- 13mm socket
- 5/16" drill bit
- Drill



- 1) Remove 3 factory bolts with 13mm socket and #27 Torx bit. (*Passenger side shown in all photos*)
- 2) Drill a 5/16" hole in each slot in the top of the mud flap.
- 3) Bolt bracket, mud flap and retainer together. Put bolts through bracket, mud flap, and retainer strap. Secure with nut. (**Make sure the threads on the bolts face towards the tire.**)
- 4) Temporarily attach the mud flap assembly to vehicle with the inner and outer most bolts removed in step 1. Mark the location on the mud flap where it lines up with the lower removed factory bolt.
- 5) Remove the mud flap assembly and drill a 5/16" hole at the location marked.
- 6) Re-attach the mud flap to the vehicle using all 3 of the factory bolts and tighten.
- 7) Repeat above steps for opposite side.

