



30802

Highbeam Headlight Relay Installation Instructions

1. Locate the loom containing the wires going to the headlights.
2. Mount the relay base on the driver's side inner fender well, close to the headlight harness.

Note: The black wire should go on the screw that holds the relay base to the vehicle. This wire must make a good ground.

3. Route the red wire to the large battery lug on the back of the alternator or the "+" battery post and attach.
4. Take the t-taps supplied in the kit and with a pair of pliers, squeeze one onto the high beam wire (Lt green on GM) and one onto the low beam wire (Tan on GM) that is in the loom going to your headlights.
5. Take the tan wire and light green wire coming out of your relay base, cut to length and crimp one male push-on terminal to each wire.
6. The terminals you crimped on, will then plug into the t-taps you installed in step 4. Be sure you match the colors up.
7. Now you are ready to mount the fuse holder to the fender well with the screw supplied.
8. Install the relay onto the relay base.
9. To test relay for proper operation, turn on headlights and cycle from high to low beam.

HIGH BEAM HEADLIGHT

