



off-road driven!™

PRO COMP SUSPENSION

**PN# 61151
2002-2005
Dodge Ram
1500 4WD
2" Torsion Bar
Key Kit**

This document contains very important information that includes warranty information and instructions for resolving problems you may encounter. Please keep it in the vehicle as a permanent record.

Part #	Description	Qty.
94-4197	TORSION BAR KEY	2
94-5160	TORSION BAR TOOL ADAPTER	1

Note: All part images may vary from catalog and instructions.

<u>RECOMMENDED PRO COMP SHOCKS</u>		
w/ 61151 Front Kit ONLY!		
<u>2002-2005 1500 4WD</u>		
	<u>Front:</u>	<u>Rear:</u>
<u>ES9000:</u>	917553	926505
<u>MX-6:</u>	MX6126	MX6036

Equipment Available from your Pro Comp Distributor!

67971: Torsion Bar Removal/Installation Tool
2002-2005 2wd Dodge Ram 1500 6" Suspension Lift Kit:56706/56706MX
2006-2008 2wd Dodge Ram 1500 6" Suspension Lift Kit:56726/56726MX: w/ Coil Spring Front End
2009-2010 4wd Dodge Ram 1500 6" Suspension Lift Kit: 56747
2006-2008 4wd Dodge Ram 1500 6" Suspension Lift Kit: 56746
2006-2008 1500 2wd Dodge Ram 1500 2 1/4" Front Spacer Kit: 61205
2009-2011 1500 2wd Dodge Ram 1500 1 3/4" Front Spacer Kit: 61185
2002-2005 1500 2wd Dodge Ram 1500 2" Front Spacer Kit: 61200
2009-2011 1500 4wd Dodge Ram 1500 2 1/2" front & 1 1/2" Rear Spacer Kit: 61180k
2002-2008 1500 2wd/4wd Dodge Ram 1500 Rear 1" Block Kit: 61251
2002-2008 1500 2wd/4wd Dodge Ram 1500 Rear 2" Block Kit: 61252
2006-2011 4wd Dodge Ram 1500 2" Front Spacer Kit: 61180

Also, Check out our outstanding selection of Pro Comp tires to compliment your new installation!

Introduction:

- ◆ This installation requires a professional mechanic!
- ◆ We recommend that you have access to a factory service manual for your vehicle to assist in the disassembly and reassembly of your vehicle. It contains a wealth of detailed information.
- ◆ Prior to installation, carefully inspect the vehicle's steering and driveline systems paying close attention to the tie rod ends, ball joints, wheel bearing preload, pitman and idler arm. Additionally, check steering-to-frame and suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition. Repair or replace all worn or damaged parts!
- ◆ Read the instructions carefully and study the illustrations before attempting installation! You may save yourself a lot of extra work.
- ◆ Check the parts and hardware against the parts list to assure that your kit is complete. Separating parts according to the areas where they will be used and placing the hardware with the brackets before you begin will save installation time.
- ◆ Check the special equipment list and ensure the availability of these tools.
- ◆ Secure and properly block vehicle prior to beginning installation.
- ◆ ALWAYS wear safety glasses when using power tools or working under the vehicle!
- ◆ Use caution when cutting is required under the vehicle. The factory undercoating is flammable. Take appropriate precautions. Have a fire extinguisher close at hand.
- ◆ Foot pound torque readings are listed on the Torque Specifications chart at the end of the instructions. These are to be used unless specifically directed otherwise. Apply thread lock retaining compound where specified.
- ◆ **Please note that while every effort is made to ensure that the installation of your Pro Comp lift kit is a positive experience, variations in construction and assembly in the vehicle manufacturing process will virtually ensure that some parts may seem difficult to install. Additionally, the current trend in manufacturing of vehicles results in a frame that is highly flexible and may shift slightly on disassembly prior to installation. The use of pry bars and tapered punches for alignment is considered normal and usually does not indicate a faulty product. However, if you are uncertain about some aspect of the installation process, please feel free to call our tech support department at the number listed on the cover page. We do not recommend that you modify the Pro Comp parts in any way as this will void any warranty expressed or implied by the Pro Comp Suspension company.**

INSTALLATION INSTRUCTIONS:


1. Measure the vehicle from the center of the hub to the fender lip and record this measurement below.

LF: _____ RF: _____

LR: _____ RR: _____


2. Be sure you are working on a level surface. Block the rear tires and raise the front of the vehicle. Support the frame with jack stands.
3. Remove the front wheels.
4. Measure the torsion bar adjusting screw depths and record this dimensions for later use on reassembly. Mark the orientation of the torsion bar in relation to the front A-arm.

LEFT: _____ RIGHT: _____




IMPORTANT!: You must measure the extended length of the front shocks at this time. If the front shocks measure 15 3/4" or less in length they must be replaced with a 17" shock. We recommend Pro Comp (PN 917553) shocks. Be sure to measure from the center of the eye loop to the stem mounting point (between the rubber bushings). The measurement may be taken while the shock is installed and fully extended.

5. Starting on the driver's side, remove the torsion bar adjusting screw. Apply a small amount of lubrication grease to the torsion bar puller threads (**67971** is recommended) and the puller shaft-to-adjuster arm contact point. Install the puller and the supplied torsion bar tool adapter (**94-5160**). Load the puller and torsion adjuster arm until the torsion bar keeper can be removed from the cross member. Release the puller to unload the torsion bar.




6. Completely remove the torsion bar key bolt from the key assembly.
7. With the bar unloaded, slide it forward out of the OE torsion bar key and remove the key from the vehicle.

NOTE: If the bar seems stuck, use a hammer and punch through the hole in the rear of the cross member to dislodge it.




8. Install the Pro Comp Forged torsion key (94-4197) and slide the torsion bar back into position. Be sure to line up the previously applied orientation marks.



IMPORTANT! Make sure Torsion Bar is extended at least 1/4" inch through the Torsion Key.

9. Using the torsion bar unloading tool and the torsion bar tool adapter, apply pressure with the torsion key to allow the torsion key keeper to be reinstalled.
10. Reinstall the OE adjusting bolt to the keeper, and reset the torsion bar preload bolts using the measurements previously taken.

IMPORTANT!: Be sure that at least 1/4" of bolt threads extend beyond torsion key keeper.



NOTE: Each 1/4" of adjustment on the bolt equals approximately 1" at the wheel.

11. Repeat steps 5 through 10 and the shock box on the Passenger Side of the vehicle.
12. Now would also be a good time to inspect the shocks for damage or fluid leakage. Replace if necessary.

NOTE: For improved performance Pro Comp shocks are recommended.



13. Install the front tires/wheels and lower the vehicle onto the ground.
14. Check ride height of the vehicle by measuring the distance between the tires and fenders making sure both sides of the truck are even. Adjust as needed.
15. Torque all bolts to factory specifications. Re-torque all bolts after 500 miles.

NOTES:

- ⇒ On completion of the installation, have the suspension and headlights re-aligned.
- ⇒ After 100 miles recheck for proper torque on all newly installed hardware.
- ⇒ Recheck all hardware for tightness after off road use.

Use this only as a guide for hardware without a called out torque specification in the instruction manual.

Bolt Torque and ID						
Decimal System			Metric System			
All Torques In Ft. Lbs. Maximums						
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 9.8	Class 10.9	Class 12.9
5/16	15	20	M6	5	9	12
3/8	30	45	M8	18	23	27
7/16	45	60	M10	32	45	50
1/2	65	90	M12	55	75	90
9/16	95	130	M14	85	120	145
5/8	135	175	M16	130	165	210
3/4	185	280	M18	170	240	290

	
<p>1/2-13x1.75 HHCS</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px;">D</div> <div style="border: 1px solid black; padding: 2px;">T</div> <div style="border: 1px solid black; padding: 2px;">L</div> <div style="border: 1px solid black; padding: 2px;">X</div> </div>	<p>M12-1.25x50 HHCS</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px;">D</div> <div style="border: 1px solid black; padding: 2px;">T</div> <div style="border: 1px solid black; padding: 2px;">L</div> <div style="border: 1px solid black; padding: 2px;">X</div> </div>
<p>Grade 5 Grade 8 (No. of Marks + 2)</p>	
<p>G = Grade (Bolt Strength) D = Nominal Diameter (Inches) T = Thread Count (Threads per Inch) L = Length (Inches) X = Description (Hex Head Cap Screw)</p>	<p>P = Property Class (Bolt Strength) D = Nominal Diameter (Millimeters) T = Thread Pitch (Thread Width, mm) L = Length (Millimeters) X = Description (Hex Head Cap Screw)</p>