



## **PRO COMP SUSPENSION**

---

[Suspension Systems that Work!](#)

**PN# 63225K  
2004-2011  
Chevy Colorado &  
GMC Canyon  
2WD  
2 1/2" Front & 1  
1/2" Rear  
Kit**

This document contains very important information that includes warranty information and instructions for resolving problems you may encounter. Please keep it in the vehicle as a permanent record.

<b>Part #</b>	<b>Description</b>	<b>Qty.</b>
94-5961	LOWER STRUT EXTENSION BRACKET: Drvr	1
94-5964	LOWER STRUT EXTENSION BRACKET: Pass	1
94-5966	LOWER STRUT EXTENSION BRACKET SLEEVE: Drvr	1
94-5968	LOWER STRUT EXTENSION BRACKET SLEEVE: Pass	1
94-8092	LCA SUPPORT SLEEVE	2
90-5970	1/2" BALL JOINT SPACER	2
94-5971	REAR SHACKLE	2
94-5973	REAR SHOCK EXTENSION	2
90-6752	<b>HARDWARE PACK:</b>	<b>1</b>
.120C700HCS1Z	12mm-1.75 X 70mm HEX BOLT Gr. 10.9	2
.120NWHDY	12mm HARDENED FLAT WASHER	4
.120CNUCZ	12mm-1.75 STOVER NUT Gr. C	2
.140C800HCS1Z	14mm-2 X 80mm HEX BOLT Gr. 10.9	4
.140NWHDY	14mm HARDENED FLAT WASHER	8
.140CNUCZ	14mm-2.0 STOVER NUT Gr. C	4
.80C400HCS1Z	8mm-1.25 X 40mm HEX BOLT Gr. 10.9	8
.80NWHDY	8mm HARDENED FLAT WASHER	16
.80CNUCZ	8mm-1.25 STOVER NUT Gr. C	8
90-6753	<b>HARDWARE PACK:</b>	<b>1</b>
.80C700HCS1Z	8mm-1.25 X 70mm HEX BOLT Gr. 10.9	4
.80NWHDY	8mm SAE HARDENED FLAT WASHER	4

*NOTE: All part images may vary from catalog and instructions.*

*Call for shock applications.*

## PLEASE NOTE:

**Due to differences in manufacturing, dimensions and inflated measurements, tire and wheel combinations should be test fit prior to installation. Tire and wheel choice is crucial in assuring proper fit, performance, and the safety of your Pro Comp equipped vehicle. For this application, we recommend no larger than a 31" X 10.5" tire on an 8" wide wheel with a backspacing of 4 1/2". Additionally, quality tire of radial design wide is also recommended. Violation of these recommendations will not be endorsed as acceptable by Pro Comp Suspension and will void any and all warranties either written or implied.**

## Introduction:

- ◆ This installation requires a professional mechanic!
- ◆ We recommend that you have access to a factory service manual for your vehicle to assist in the disassembly and reassembly of your vehicle. It contains a wealth of detailed information.
- ◆ Prior to installation, carefully inspect the vehicle's steering and driveline systems paying close attention to the tie rod ends, ball joints, wheel bearing preload, pitman and idler arm. Additionally, check steering-to-frame and suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition. Repair or replace all worn or damaged parts!
- ◆ Read the instructions carefully and study the illustrations before attempting installation! You may save yourself a lot of extra work.
- ◆ Check the parts and hardware against the parts list to assure that your kit is complete. Separating parts according to the areas where they will be used and placing the hardware with the brackets before you begin will save installation time.
- ◆ Check the special equipment list and ensure the availability of these tools.
- ◆ Secure and properly block vehicle prior to beginning installation.
- ◆ **ALWAYS** wear safety glasses when using power tools or working under the vehicle!
- ◆ Use caution when cutting is required under the vehicle. The factory undercoating is flammable. Take appropriate precautions. Have a fire extinguisher close at hand.
- ◆ Foot pound torque readings are listed on the Torque Specifications chart at the end of the instructions. These are to be used unless specifically directed otherwise. Apply thread lock retaining compound where specified.
- ◆ **Please note that while every effort is made to ensure that the installation of your Pro Comp lift kit is a positive experience, variations in construction and assembly in the vehicle manufacturing process will virtually ensure that some parts may seem difficult to install. Additionally, the current trend in manufacturing of vehicles results in a frame that is highly flexible and may shift slightly on disassembly prior to installation. The use of pry bars and tapered punches for alignment is considered normal and usually does not indicate a faulty product. However, if you are uncertain about some aspect of the installation process, please feel free to call our tech support department at the number listed on the cover page. We do not recommend that you modify the Pro Comp parts in any way as this will void any warranty expressed or implied by the Pro Comp Suspension company.**

## FRONT INSTALLATION:

1. Measure the vehicle from the center of the hub to the fender lip and record this measurement below.

LF: \_\_\_\_\_ RF: \_\_\_\_\_

LR: \_\_\_\_\_ RR: \_\_\_\_\_


2. Be sure you are working on a level surface. Block the rear tires and raise the front of the vehicle. Support the frame with jack stands. Use floor jacks to support the axle so it can be lifted and lowered relative to the vehicle.
3. Remove the front wheels.
4. Unclip the ABS line from the upper A-arm.




5. Unbolt the ABS line retaining bracket. Save the hardware for reuse.




6. Unbolt the upper sway bar end link from the sway bar. Save the hardware for reuse.



7. Unbolt the tie rod end nut and separate from the knuckle using the appropriate tool.




8. Starting on the driver's side, remove the lower strut bolt from the lower control arm.



**NOTE: The direction of the bolt for reinstallation.**

9. Support the lower A-arm with a floor jack and unbolt the (4) OE upper ball joint retaining nuts and bolts.
10. Remove the upper strut nut on the strut tower (3) on each side of the vehicle that holds the strut assembly to the strut tower.



11. Remove the strut assembly from the vehicle.




12. Now would be a good time to inspect the front struts for damage or fluid leakage. Replace if necessary.


**NOTE: For improved performance**

**Pro Comp struts/shocks are recommended. See the box on page 2 for applications.**

13. Unbolt and remove the lower ball joint nut and bolt located behind the sway bar link.




14. Install the lower strut extension bracket sleeve (94-8092) into the original lower mount.
15. Install the lower strut extension bracket (94-5961 drvr and 94-5964 pass) in to the original lower mount. Secure using the supplied 14mm X 80mm bolt and hardware. Leave loose at this time.




**IMPORTANT!: Make sure the welded ears on the tab face inward.**

16. Secure the remaining mounting hole in the lower strut extension bracket (94-5961 drvr and 94-5964 pass) using the


supplied **12mm X 70mm** bolt and hardware. Leave loose at this time.




17. Install the strut assembly into the strut tower and secure using the previously removed (3) OE nuts. (Make sure the bottom of the strut is aligned properly) Leave loose at this time.
18. Install the lower strut mount into the extension bracket (**94-5961 drvr and 94-5964 pass**). Secure using the supplied **14mm X 80mm** bolt and hardware.



19. Torque all of the strut hardware to factory specifications or the torque chart on page 9.
20. Using the floor jack, raise the lower control arm and reinstall the sway bar end link to the sway bar. Secure using the previously removed OE hardware.



21. Using the floor jack, raise the lower control arm and reinstall the OE upper ball joint to the upper A-arm using the (1 per side) 1/2" upper ball joint spacer (90-5970) and the supplied **8mm X 40mm** bolts and hardware.



22. Reattach the ABS line to the upper A-arm using the previously removed OE hardware.
23. Secure the ABS line retaining bracket using the previously removed OE nut.
24. Reinstall the tie rod end to the knuckle. Torque to factory specifications.
25. Repeat steps 4 through 24 on the remaining side of the vehicle.
26. Install the front tires/wheels and lower the vehicle onto the ground. torque the lug nuts according to manufacturer's speci-



cations.

27. Recheck all previously loosened hardware.
28. Torque all bolts to factory specifications. Re-torque all bolts after 500 miles.

***IMPORTANT! BE SURE TO BRING THE VEHICLE IMMEDIATELY TO A REPUTABLE ALIGNMENT SHOP TO BE ALIGNED!***

**NOTES:**

- ⇒ On completion of the installation, have the suspension and headlights re-aligned.
- ⇒ After 100 miles recheck for proper torque on all newly installed hardware.
- ⇒ Recheck all hardware for tightness after off road use.

## REAR INSTALLATION:

1. Block the front tires and raise the rear of the vehicle. Support the frame with jack stands forward of the rear springs.
2. Remove the rear wheels.
3. Lower and remove the spare tire from the vehicle.



4. Support the rear axle with a floor jack and unbolt the (2) OE upper shock bolts.



5. Now would be a good time to inspect the shocks for damage or fluid leakage. Replace if necessary.


***NOTE: For improved performance Pro Comp shocks are recommended. See the box on page 2 for applications.***

6. Unbolt the (2) nuts on the rear leaf spring shackle. Remove the (2) nuts and bolts. Save for reinstallation.




**NOTE:** *The position of the bolts before removing them.*

7. Remove the rear shackle from the vehicle.
8. Using the floor jack, lower the rear axle until there is adequate room to install the new PRO COMP rear shackle (**94-5971**) using the previously removed **OE** bolts and hardware.



**NOTE:** *Be sure to reinstall the bolts in the same position they were removed.*

9. Torque the shackle hardware to manufacturers specifications.
10. Install the rear shock extension bracket (**94-5973**) and reattach the rear shock to the upper mount using the supplied **8mm X 70mm** bolts and hardware.



11. Torque the shock hardware to 22ft./lbs.
12. Repeat the steps 4 Through 11 on the remaining side of the vehicle.
13. Check all hardware at this time to ensure that everything is tight. Check for adequate clearance on all brake lines and emergency brake cables. Make sure you check with the suspension fully extended, and compressed.
14. Reinstall the spare tire to it's original position.
15. Reinstall the wheels and lower the vehicle to the ground. Torque the lug nuts according to the wheel manufacturers recommendations.
16. Torque all bolts to factory specifications. Re-torque all bolts after 500 miles.

### **NOTES:**

- ⇒ **On completion of the installation, have the suspension and headlights re-aligned.**
- ⇒ **After 100 miles recheck for proper torque on all newly installed hardware.**
- ⇒ **Recheck all hardware for tightness after off road use.**



Use this only as a guide for hardware without a called out torque specification in the instruction manual.

<b>Bolt Torque and ID</b>						
<b>Decimal System</b>			<b>Metric System</b>			
All Torques in Ft. Lbs. Maximums						
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 9.8	Class 10.9	Class 12.9
5/16	15	20	M6	5	9	12
3/8	30	45	M8	18	23	27
7/16	45	60	M10	32	45	50
1/2	65	90	M12	55	75	90
9/16	95	130	M14	85	120	145
5/8	135	175	M16	130	165	210
3/4	185	280	M18	170	240	290

1/2-13x1.75 HHCS      **Grade 5    Grade 8**  
(No. of Marks + 2)

D    T    L    X

G = Grade (Bolt Strength)  
D = Nominal Diameter (Inches)  
T = Thread Count (Threads per Inch)  
L = Length (Inches)  
X = Description (Hex Head Cap Screw)

M12-1.25x50 HHCS

D    T    L    X

P = Property Class (Bolt Strength)  
D = Nominal Diameter (Millimeters)  
T = Thread Pitch (Thread Width, mm)  
L = Length (Millimeters)  
X = Description (Hex Head Cap Screw)

**Notice to Owner operator, Dealer and Installer:**

Vehicles that have been enhanced for off-road performance often have unique handling characteristics due to the higher center of gravity and larger tires. This vehicle may handle, react and stop differently than many passenger cars or unmodified vehicles, both on and off-road. You must drive your vehicle safely! Extreme care should always be taken to prevent vehicle rollover or loss of control, which can result in serious injury or even death. Always avoid sudden sharp turns or abrupt maneuvers and allow more time and distance for braking! Pro Comp reminds you to fasten your seat belts at all times and reduce speed! We will gladly answer any questions concerning the design, function, maintenance and correct use of our products.

**Please make sure your Dealer/Installer explains and delivers all warning notices, warranty forms and instruction sheets included with Pro Comp product.**

Application listings in this catalog have been carefully fit checked for each model and year denoted. However, Pro Comp reserves the right to update as necessary, without notice, and will not be held responsible for misprints, changes or variations made by vehicle manufacturers. Please call when in question regarding new model year, vehicles not listed by specific body or chassis styles or vehicles not originally distributed in the USA.

**Please note that certain mechanical aspects of any suspension lift product may accelerate ordinary wear of original equipment components.** Further, installation of certain Pro Comp products may void the vehicle's factory warranty as it pertains to certain covered parts; it is the consumer's responsibility to check with their local dealer for warranty coverage before installation of the lift.